



# Service Manual

PMD330 /N1M, /U1B, /F1B  
PMD331 /N1M, /U1B, /F1B  
PMD340 /N1M, /U1B, /F1M  
CD Player

PMD330



PMD331 / 340



## TABLE OF CONTENTS

SECTION	PAGE
1. TECHNICAL SPECIFICATIONS .....	1
2. SERVICE HINTS .....	2
3. SERVICE TOOLS .....	2
4. ADJUSTMENT AND SERVICE MODE .....	3
5. MICROPROCESSOR AND IC DATA .....	5
6. WIRING DIAGRAM .....	13
7. BLOCK DIAGRAM .....	15
8. SCHEMATIC DIAGRAM.....	17
9. PARTS LOCATIONS .....	24
10. EXPLODED VIEW AND MECHANISM PARTS LIST .....	28
11. TECHNICAL DESCRIPTION .....	31
12. ELECTRICAL PARTS LIST .....	33

Please use this service manual with referring to the user guide ( D.F.U. ) without fail.

修理の際は、必ず取扱説明書を準備し操作方法を確認の上作業を行ってください。

# marantz®

## PMD330 / 331 / 340

371K855010 MIT  
3120 785 22250  
First Issue 1999.12

## MARANTZ DESIGN AND SERVICE

Using superior design and selected high grade components, **MARANTZ** company has created the ultimate in stereo sound. Only original **MARANTZ** parts can insure that your **MARANTZ** product will continue to perform to the specifications for which it is famous.

Parts for your **MARANTZ** equipment are generally available to our National Marantz Subsidiary or Agent.

### ORDERING PARTS :

Parts can be ordered either by mail or by Fax.. In both cases, the correct part number has to be specified.

The following information must be supplied to eliminate delays in processing your order :

1. Complete address
2. Complete part numbers and quantities required
3. Description of parts
4. Model number for which part is required
5. Way of shipment
6. Signature : any order form or Fax. must be signed, otherwise such part order will be considered as null and void.

#### USA

**MARANTZ AMERICA, INC.**  
440 MEDINAH ROAD  
ROSELLE, ILLINOIS 60172  
USA  
PHONE : 630 - 307 - 3100  
FAX : 630 - 307 - 2687

#### EUROPE / TRADING

**MARANTZ EUROPE B.V.**  
P.O.BOX 80002, BUILDING SFF2  
5600 JB EINDHOVEN  
THE NETHERLANDS  
PHONE : +31 - 40 - 2732241  
FAX : +31 - 40 - 2735578

#### BRAZIL

**PHILIP DA AMAZONIA IND. ELET. ITDA**  
CENTRO DE INFORMACOES AO  
CEP 04698-970  
SAO PAULO, SP, BRAZIL  
PHONE : 0800 - 123123(Discagem Direta Gratuita)  
FAX : +55 11 534. 8988

**PROFESSIONAL AMERICAS**  
**SUPERSCOPE TECHNOLOGIES, INC.**  
MARANTZ PROFESSIONAL PRODUCTS  
2640 WHITE OAK CIRCLE, SUITE A  
AURORA, ILLINOIS 60504 USA  
PHONE : 630 - 820 - 4800  
FAX : 630 - 820 - 8103

**PROFESSIONAL AUSTRALIA**  
**TECHNICAL AUDIO GROUP PTY, LTD**  
558 DARLING STREET,  
BALMAIN, NSW 2041,  
AUSTRALIA  
PHONE : 61 - 2 - 9810 - 5300  
FAX : 61 - 2 - 9810 - 5355

#### CANADA

**LENBROOK INDUSTRIES LIMITED**  
633 GRANITE COURT,  
PICKERING, ONTARIO L1W 3K1  
CANADA  
PHONE : 905 - 831 - 6333  
FAX : 905 - 831 - 6936

#### AUSTRALIA

**JAMO AUSTRALIA PTY LTD**  
1 EXPO COURT, P.O. BOX 350  
MT. WAVERLEY VIC 3149  
AUSTRALIA  
PHONE : +61 - 3 - 9543 - 1522  
FAX : +61 - 3 - 9543 - 3677

#### THAILAND

**MRZ STANDARD CO.,LTD**  
746 - 754 MAHACHAI ROAD.,  
WANGBURAPAPIROM, PHRANAKORN,  
BANGKOK, 10200 THAILAND  
PHONE : +66 - 2 - 222 9181  
FAX : +66 - 2 - 224 6795

#### SINGAPORE

**WO KEE HONG (S) PTE LTD**  
WO KEE HONG CENTRE  
NO.23, LORONG 8, TOA PAYOH  
SINGAPORE 319257  
PHONE : +65 2544555  
FAX : +65 2502213

#### NEW ZEALAND

**WILDASH AUDIO SYSTEMS NZ**  
14 MALVERN ROAD MT ALBERT  
AUCKLAND NEW ZEALAND  
PHONE : +64 - 9 - 8451958  
FAX : +64 - 9 - 8463554

#### TAIWAN

**PAI- YUING CO., LTD.**  
6 TH FL NO. 148 SUNG KIANG ROAD,  
TAIPEI, 10429, TAIWAN R.O.C.  
PHONE : +886 - 2 - 25221304  
FAX : +886 - 2 - 25630415

#### MALAYSIA

**WO KEE HONG ELECTRONICS SDN. BHD.**  
SUITE 8.1, LEVEL 8, MENARA GENESIS,  
NO. 33, JALAN SULTAN ISMAIL,  
50250 KUALA LUMPUR, MALAYSIA  
PHONE : +60 3 - 2457677  
FAX : +60 3 - 2458180

#### JAPAN *Technical*

**MARANTZ JAPAN, INC.**  
35- 1, 7- CHOME, SAGAMIONO  
SAGAMIHARA - SHI, KANAGAWA  
JAPAN 228-8505  
PHONE : +81 42748 1013  
FAX : +81 42741 9190

#### 日本マランツ株式会社

本 社 〒228-8505  
神奈川県相模原市相模大野7-35-1  
営業本部 〒150-0022  
東京都渋谷区恵比寿南1-11-9

#### KOREA

**MK ENTERPRISES LTD.**  
ROOM 604/605, ELECTRO-OFFICETEL, 16-58,  
3GA, HANGANG-RO, YONGSAN-KU, SEOUL  
KOREA  
PHONE : +822 - 3232 - 155  
FAX : +822 - 3232 - 154

### SHOCK, FIRE HAZARD SERVICE TEST :

**CAUTION :** After servicing this appliance and prior to returning to customer, measure the resistance between either primary AC cord connector pins ( with unit NOT connected to AC mains and its Power switch ON ), and the face or Front Panel of product and controls and chassis bottom.

Any resistance measurement less than 1 Megohms should cause unit to be repaired or corrected before AC power is applied, and verified before it is return to the user/customer.

Ref. UL Standard No. 813.

In case of difficulties, do not hesitate to contact the Technical  
Department at above mentioned address.

1. TECHNICAL SPECIFICATIONS

		PMD330	PMD331 / PMD340
General specifications			
System		Compact Disc - Digital Audio	
Number of channels		2	
Compatible discs		CD-DA, CD-R, CD-RW (12 cm, 8 cm)	
Audio characteristics			
Channels		2 channels	
Frequency characteristics		20 Hz to 20 kHz +/- 0.3 dB	
Dynamic range		≥ 90 dB (1 kHz)	
S/N ratio		≥ 100 dB (1 kHz)	
Total harmonic distortion (THD)		0.005 % (1 kHz)	
Wow and flutter		Quartz precision	
Error correction method		Cross-interleave Read-Solomon code (CIRC)	
Analog output	Pin jack,unbalanced (RCA)	2.0V RMS Stereo	
	XLR jack,balanced (XLR) (variable range)	—— ——	+16 dBu /600 Ω, @ 0 dB FS (-11 dBu to +21 dBu, variable)
Digital output	Pin jack (SPDIF)	0.5 Vp-p/75 Ω	
	XLR jack (SPDIF)	——	3.5 Vp-p/110 Ω
	optical connector	——	-19 dBm
Search precision		1 frame	
Pitch control		Maximum: +/-12% in 0.1% steps	
Pitch bend control		——	+/- 8 %
Strat timing		——	20 ms
Remote control			
Infrared remote control input		IN (IR sensor)	
RC5 remote control input/output		——	RCA IN (INT/EXT switch)/OUT
Remote control input/output		——	D-SUB 25-Pin female
Optical anning method			
Laser		AlGaAs semiconductor	
Wavelength		780 nm	
Signal system			
Sampling frequency		44.1 kHz	
Quantization		16-bit linear/channel	
Power supply section			
AC power supply		/F : 100V, AC 50/60Hz, /N : 230V, AC 50Hz, /U : 120V, AC 60Hz	
Power consumption		12 W	17 W
Cabinet, etc.			
External dimensions (W x H x D)		483 x 100 x 325 mm (19 x 3-15/16 x 12- 13/16 inches)	
Weight		4.8 kg (10.6 lbs)	4.9 kg (10.8 lbs)
Operating temperature range		+ 5°C to + 35°C	
Operating humidity range		5% to 90% (without dew)	

Due to our continuing efforts to improve our products, the specifications and appearance of this product are subject to change without prior notice.

2. SERVICE HINTS

GENERAL

SERVICE PACKAGE

DISMOUNTING

A: VACUUM PISTON 4822 395 10082, SOLDERING IRON, e.g. WELDER solder tip PT-H7

B: SOLDERING IRON, SOLDER WICK 4822 321 40042, e.g. A PAIR OF TWEEZERS, HEATING

C: SOLDERING IRON, SOLDER WICK, CLEANING

MOUNTING

A: e.g. A PAIR OF TWEEZERS, SOLDER ø0.5-0.8mm, PRESSURE

B: SOLDERING IRON, SOLDER ø0.5-0.8mm, PRESSURE, SOLDERING IRON, SOLDERING TIME < 3 sec/side

EXAMPLES

CORRECT

INCORRECT

PRECAUTIONS

CORRECT

INCORRECT

CHIP COMPONENT

3. SERVICE TOOLS

Audio signals disc	4822 397 30184
Disc without errors (SBC444)+	
Disc with DO errors, black spots and fingerprints (SBC444A)	4822 397 30245
Disc (65 min 1kHz) without no pause	4822 397 30155
Max. diameter disc (58.0 mm)	4822 397 60141
Torx screwdrivers	
Set (straight)	4822 395 50145
Set (square)	4822 395 50132
13th order filter	4822 395 30204

4. ADJUSTMENT AND SERVICE MODE

1.1. Digital Output (Coaxial) Check

On the preset menu, set "D.OUT" to "ON".(PMD331/PMD340)  
Do waveform observation with the oscilloscope, and confirm the digital output level of JT01 to be 0.5Vp-p, square wave within ±20% .

1.2. Balanced Output Adjustment (PMD331/PMD340)

1kHz, 0 dB are played back by using TEST disc.  
Turn RB01 on the rear panel, and adjust the output of JB53 (Balanced Out L-CH).  
Turn RB02 on the rear panel, and adjust the output of JB54 (Balanced Out R-CH).  
Adjust each output level to 16 dBu, within ±0.5dB.

1.3. Service Mode

- 1) With power off, simultaneously press the PLAY/PAUSE, MODE and TIME buttons, and at the same time, press the power button. At this time the LCD shows the model name and firmware version.
- 2) Next, press CUE button.
- 3) At this time the LCD shows " Test : Version ". (TEST MODE select menu)
- 4) The NEXT and PREVIOUS buttons change the TEST MODE(refer to the chart below). The PLAY button selects it.
- 5) Pressing the CUE button returns to the TEST MODE select menu.
- 6) Press the STOP button to exit the service mode.

INDEX	TEST MODE	CONTENTS
1.3.1	Version	MPU firmware version check
1.3.2	Display	LCD&LED test
1.3.3	Key&GPI	Confirmation of Buttons, GPI Control I/O and RC5
1.3.4 *	EE-PROM	Check of EEPROM Read/Write
1.3.5 *	Pickup	Manual moving of the pickup

\* It is not usually necessary to confirm.

1.3.1. Model name and firmware version check

When the LCD shows "Test : Version", press the PLAY button, to see the model name and the MPU firmware version.  
Pressing the CUE button returns to the TEST MODE select menu.

1.3.2. LCD and LED test

- 1) Set the LCD panel contrast adjustment screw to mechanical center. (you will feel a click.)
- 2) When the LCD shows "Test : Display", press the PLAY button.
- 3) The LCD and LED lights as the chart below.
- 4) Each time the PLAY/PAUSE button is pressed the LCD and LED change as shown in the chart below.
- 5) Pressing the CUE button returns to the TEST MODE select menu.

	LCD	BUTTON				GPI Control I/O					
		END	PITCH	PLAY	CUE	PLAY TALLY	PAUSE TALLY	CUE TALLY	FADER TALLY	INDEX	END TALLY
①	PATTERN 1	○	×	○	×	○	×	○	×	○	×
②	PATTERN 2	×	○	×	○	×	○	×	○	×	○
③	All light up	○	○	○	○	○	○	○	○	○	○
④	None light up	×	×	×	×	×	×	×	×	×	×

○ : Light    × : Not Light

4. 調整とサービスモード

1.1. Digital Output (Coax) 確認

Preset Menu で "D.OUT" を "ON" に設定する。(PMD331/PMD340)  
JT01のデジタル出力レベルをオシロスコープで波形観測をおこない 0.5Vp-p, +/-20%以内の矩形波である事を確認する。

1.2. Balanced Output 調整 (PMD331/PMD340)

TEST Disc を使用し 1kHz, 0dB を再生する。  
背面パネルのRB01を回してJB53 (Balanced Out L-Ch)の出力を調整する。  
背面パネルのRB02を回してJB54 (Balanced Out R-Ch)の出力を調整する。  
各々の出力レベルを 16dBu, +/-0.5dB 以内に調整する。

1.3. SERVICE モードでの確認

電源OFFの状態で、Play/Pause ボタン、Modeボタン、Time ボタンを同時に押しながら電源を入れる。  
または電源ONの状態で赤外線リモコンからサービスコードを送ることにより、サービスモードに入る。この時、LCDにはモデル名とMPUファームウェアのバージョン表示される。  
次に、CUEボタンを押す。  
この時、LCDの表示が "Test : Version " となる。(Test mode 選択画面)  
NextとPrevious ボタンでTest mode(下表参照)を切り替え、Play ボタンで選択する。  
CUEボタンでTest mode 選択画面の状態に戻る。  
Stopボタンでサービスモードを終了する。

確認項目	Test mode	内容
1.3.1	Version	MPU のファームウェアのバージョン表示
1.3.2	Display	LCD&LED 表示点灯テスト
1.3.3	Key&GPI	ボタン、GPI Control I/O, RC5 の入力表示
1.3.4 *	EE-PROM	EEPROM Read/Write のチェック
1.3.5 *	Pickup	ピックアップを手動で動作させる

\* 印の項目は通常確認の必要は無い。

1.3.1. モデル名／プログラムバージョンの確認


"Test : Version" と表示されているときに、Play ボタン押すと、モデル名とMPUファームウェアのバージョンが表示される。  
CUEボタンを押すと Test mode 選択画面 の状態に戻ります。

1.3.2. LCD 表示& LED点灯の確認

あらかじめ前面パネルのコントラスト調整用ボリュームRYO1をメカニカルセンターでクリックする位置に調整する。  
"Test : Display " と表示されているときに、Play ボタン押すと、下記表に従ってLCDとLEDが点灯される。 Play ボタンを押す毎にLCDとLEDは下表の順に表示・点灯が切り替わる。  
CUEボタンを押すと Test mode 選択画面 の状態に戻ります。


PATTERN 1

-パターン1表示



PATTERN 2

-パターン2表示



1.3.3. Confirmation of Buttons, GPI Control I/O and RC5

- 1) When the LCD shows "Test : Key&GPI", press the PLAY button.
- 2) The LCD shows "No Signal".
- 3) Press a button, GPI Control I/O and RC5 are input, and the LCD changes as shown in the chart below.

FUNCTION	SW Input	GPI * Input	RC5 Input	FUNCTION	SW Input	GPI * Input	RC5 Input
Open/Close	28	--	29	Preset	33	--	34
Time	29	--	30	Index +	17	8	18
CD-Text	30	--	31	Index -	18	9	19
Mode	31	--	32	0	1	--	2
Stop ***	--	--	--	1	2	--	3
Cue ****	--	--	--	2	3	--	4
Play/Pause	11	--	--	3	4	--	5
Play	--	1	12	4	5	--	6
Cue + Play	13	4	--	5	6	--	7
Pause	--	2	13	6	7	--	8
Next	15	10	16	7	8	--	9
Previous	16	11	17	8	9	--	10
FF	19	6	20	9	10	--	11
REW	20	7	21	Pitch Bend +*	26	--	27
END	22	--	23	Pitch Bend -*	27	--	28
A-B Repeat	21	--	22	Service	--	--	35
Pitch +	24 **	13	25	Fader (Normal)	--	Fader Input	--
Pitch -	25 **	14	26	Fader (Invert)	--	Fader Input	--
Program	32	--	33				
Pitch On/Off	23	15	24				

\* : PMD331, PMD340 only.

\*\* : PMD330 only.

\*\*\* : The service mode is exited.

\*\*\*\* : The TEST MODE select menu is returned.

1.3.4. Check of EEPROM Read/Write

- 1) When the LCD shows "Test : EE-PROM", press the PLAY button.
- 2) Check of EEPROM Read/Write begins. The check takes about 1 minute. During the check pressing any button has no effect.
- 3) At this time the LCD shows as the following order.  
"ADDR (LOW)"--->"WRITE (LOW)"--->"WRITE (HIGH)"--->"PAGE WRITE"--->"EEPROM OK!"
- 4) If there is an error in the EEPROM, the LCD shows "EEPROM NG!".
- 5) Pressing the CUE button returns to the TEST MODE select menu.

1.3.5. Manual moving of Pick up

- 1) When the LCD shows "Test : Pickup", press the PLAY button.
- 2) The LCD shows "Laser power". The laser diode turns on.
- 3) Press the NEXT button. The sled will move to the outside.
- 4) Press the PREVIOUS button. The sled will move to the inside.
- 5) Pressing the CUE button returns to the TEST MODE select menu.

1.3.3. ボタン、GPI Control I/O, RC5 の確認

"Test : Key&GPI" と表示されているときに、Play ボタン押すと "No Signal" と表示が変わり入力された信号源と種類を下記の表に従いLCDに表示する。

\* : PMD331, PMD340 のみ。

\*\* : PMD330 のみ。

\*\*\* : サービスモードが終了する。

\*\*\*\* : Test mode 選択画面 の状態に戻ります。

1.3.4. EEPROM のRead/Writeチェック

"Test : EE-PROM" と表示されているときに、Play ボタン押すとEEPROMのRead/Write チェックを始めます。チェックに要する時間は約1分間です。  
チェック中は一切のボタン操作が無効となります。  
この時LCDには "ADDR (LOW)" --> "WRITE (LOW)" --> WRITE (HIGH) --> "PAGE WRITE" --> "EEPROM OK !" のように表示されます。  
EEPROMに不具合がある場合は、"EEPROM NG !" が表示されます。  
CUEボタンを押すと Test mode 選択画面 の状態に戻ります。

1.3.5. Pickup の手動移動

"Test :Pickup" と表示されているときに、Play ボタン押すと "Laser power" と表示が変わりLaser Diode がONします。  
Nextボタンで外周へ、Previous ボタンで内周ヘスレッドが移動します。  
CUEボタンを押すと Test mode 選択画面 の状態に戻ります。



5. MICROPROCESSOR AND IC DATA


QU01 : H8/3062

PIN No.	PORT NAME	DEV ICE I/O	I/O	ACTIVE	INITIAL	PULL UP/DOWN	SIGNAL NAME	CONNECT DEVICE NAME	CONNECT DEVICE PORT	FUNCTION
1	Vcc	sys	--	--	--	--	VCC			Connected to the system power supply (+5V).
2	PB0 /TP8/TMO0	I/O	O	--	Low	--	LCD_RS	HD66712	RS	LCD driver register select. Instruction "L". Data register "H".
3	PB1 /TP9/TMO1	I/O	O	--	High	--	LCD_RW	HD66712	RW	LCD driver READ/WRITE. READ "H", WRITE "L".
4	PB2 /TP10/TMO2	I/O	O	--	Low	--	LCD_E	HD66712	E	LCD driver enable. Data READ/WRITE active signal.
5	PB3 /TP11/TMO3	I/O	O	Low	High	--	LCD_RESET	HD66712	RESET	LCD driver reset. Normal "H", Reset "L".
6	PB4 /TP12	I/O	I/O	--	Low	--	LCD_DB4	HD66712	DB4	LCD driver data bit 0.
7	PB5 /TP13	I/O	I/O	--	Low	--	LCD_DB5	HD66712	DB5	LCD driver data bit 1.
8	PB6 /TP14	I/O	I/O	--	Low	--	LCD_DB6	HD66712	DB6	LCD driver data bit 2.
9	PB7 /TP15	I/O	I/O	--	Low	--	LCD_DB7	HD66712	DB7	LCD driver data bit 3.
10	RESO // FWE	sys	I	Low	Low	EXT_DW	FEW	74HC00		FLASH MPU program enable signal. Enabled "H".
11	Vss	sys	--	--	--	--	VSS			Connected to the system power supply (0V).
12	PB0/TxD0	O	O	--	Low	--	DEBUG_TXD			TXD for debug mode.
13	PB1/TxD1	O	O	--	Low	--	FLASH_TXD			TXD for FLASH MPU program.
14	PB2/RxD0	I	I	--	Low	--	DEBUG_RXD			RXD debug mode.
15	PB3/RxD1	I	I	--	High	INT UP	CXD_SQSO /FLASH_RXD	CXD2585Q /74HC00	SQSO	Sub-Q 80bit/PCM peak level data input & CD-TEXT data input./RXD for FLASH MPU program.
16	PB4 /SCK0/IRQ4	I/O	I	--	Low	EXT_DW	SIF_SO	74HC165		Parallel to serial IC (74HC165) data input.
17	PB5 /SCK1/IRQ5	I/O	O	--	High	INT UP	CXD_SQCK	CXD2585Q	SQCK	Read out clock output for SQSO.
18	PA0	I/O	O	--	High	OPEN	ESA_SDTI	RL5C357	SDTI	Serial data output for ESA.
19	PA1	I/O	O	--	High	OPEN	ESA_SCK	RL5C357	SCK	Serial clock data output for ESA.
20	PA2	I/O	O	--	High	OPEN	ESA_XLT	RL5C357	XLT	Serial latch data output for ESA.
21	PA3	I/O	O	Low	High	OPEN	ESA_XSOE	RL5C357	XSOE	Enabled signal for ESA serial data. Enable "L".
22	Vss	sys	--	--	--	--	VSS			Connected to the system power supply (0V).
23	PA4	I/O	O	Low	High	OPEN	ESA_XRST	RL5C357	XRST	System reset output for ESA. Reset "L".
24	PA5	I/O	O	Low	High	OPEN	ESA_XWRE	RL5C357	XWRE	Write enable output for ESA. Enable "L".
25	PA6	I/O	O	Low	High	OPEN	ESA_XQOK	RL5C357	XQOK	Sub-code Q signal output for ESA. OK "L".
26	PA7	I/O	I	--	High	EXT_DW	ESA_SDT0	RL5C357	SDT0	Serial data input from ESA.
27	PA0	I/O	I	Low	High	EXT_DW	ESA_XWIH	RL5C357	XWIH	Write enable signal from ESA. Disable "L".
28	PA1	I/O	I	High	Low	EXT_DW	ESA_CHDT	RL5C357	CHDT	Data monitor input from ESA. Monitoring "H".
29	PA2	I/O	O	High	Low	--	CXD_RW_SEL	CXD2585Q	LOCK	RF gain select for CD-RW CD-RW "H", CD-DA & CD-R "L".
30	PA3	I/O	O	High	Low	--	CXD_LDON			Laser diode ON/OFF control.
31	PA4	I/O	I	Low	Low	--	CXD_FOK	CXD2585Q	FOK	Focus lock detect input.

PIN No.	PORT NAME	DEV ICE I/O	I/O	ACTIVE	INITIAL	PULL UP/DOWN	SIGNAL NAME	CONNECT DEVICE NAME	CONNECT DEVICE PORT	FUNCTION
32	PA5	I/O	I	Low	Low	--	CXD_LOCK	CXD2585Q	LOCK	GFS lock input.
33	PA6	I/O	I	Low	Low	--	CXD_SSTP	CXD2585Q	SSTP	Disc inside detect input.
34	PA7	I/O	O	Low	High	--	CXD_XRST	CXD2585Q	XRST	System reset output. Reset "L".
35	Vcc	sys	--	--	--	--	VCC			Connected to the system power supply (+5V).
36	PA10	I/O	O	High	Low	--	CXD_DOUT_OFF	CXD2585Q	MD2	Digital audio data output ON/OFF. ON "H".
37	PA11	I/O	O	High	High	--	CXD_MUTE	CXD2585Q	MUTE	Mute control output. Mute "H".
38	PA12	I/O	O	--	High	--	CXD_DATA	CXD2585Q	DATA	Serial data output for CXD2585Q.
39	PA13	I/O	O	--	High	--	CXD_XLAT	CXD2585Q	XLAT	Serial latch data output for CXD2585Q.
40	PA14	I/O	O	--	High	--	CXD_CLOK	CXD2585Q	CLOK	Serial clock data output. For CXD2585Q.
41	PA15	I/O	O	--	High	--	CXD_SCLK	CXD2585Q	SCLK	Clock output for SENS serial data read.
42	PA16	I/O	I	--	Low	--	CXD_SENS	CXD2585Q	SENS	SENS signal input.
43	PA17	I/O	I	--	Low	EXT_DW	CXD_EMPH	CXD2585Q	EMPH	Emphasis enable/disable input. Enable "H", Disable "L".
44	Vss	sys	--	--	--	--	VSS			Connected to the system power supply (0V).
45	PA20	I/O	I	Low	High	EXT UP	SW_DATA0	KEY INPUT		Key matrix signal input.
46	PA21	I/O	I	Low	High	EXT UP	SW_DATA1	KEY INPUT		Key matrix signal input.
47	PA22	I/O	I	Low	High	EXT UP	SW_DATA2	KEY INPUT		Key matrix signal input.
48	PA23	I/O	I	Low	High	EXT UP	SW_DATA3	KEY INPUT		Key matrix signal input.
49	PA24	I/O	I	Low	High	EXT UP	SW_DATA4	KEY INPUT		Key matrix signal input.
50	PA25	I/O	I	Low	High	EXT UP	SW_DATA5	KEY INPUT		Key matrix signal input.
51	PA26	I/O	I	Low	High	EXT UP	SW_DATA6	KEY INPUT		Key matrix signal input.
52	PA27	I/O	I	Low	High	EXT UP	SW_DATA7	KEY INPUT		Key matrix signal input.
53	PA50	I/O	O	--	High	--	SW_SCAN0	KEY SCAN		Key matrix signal output.
54	PA51	I/O	O	--	High	--	SW_SCAN1	KEY SCAN		Key matrix signal output.
55	PA52	I/O	O	--	High	--	SW_SCAN2	KEY SCAN		Key matrix signal output.
56	PA53	I/O	O	--	High	--	SW_SCAN3	KEY SCAN		Key matrix signal output.
57	Vss	sys	--	--	--	--	VSS			Connected to the system power supply (0V).
58	PA60	I/O	O	--	Low	--	SIF_ST	74HC4094	STR	Serial strobe data output for serial to parallel IC (74HC4094).
59	PA61	I/O	O	--	Low	OPEN	SIF_LD	74HC165	LS/	Serial load data output for serial to parallel IC (74HC4094).
60	PA62	I/O	O	--	Low	--	SIF_SI	74HC4094	DA	Serial data output for serial to parallel IC (74HC4094).
61	PA67/Φ	--	--	--	--	OPEN	PAI			System clock output.
62	STBY/	sys	I	High	High	EXT_UP	STBY			Standby mode input for MPU. Normal mode "H".
63	RES/	sys	I	Low	High	EXT_UP	RES			System reset input for MPU. Reset "L".
64	NMI	sys	I	--	Low	EXT_DW	NMI			Not used.
65	Vss	sys	--	--	--	--	VSS			Connected to the system power supply (0V).
66	EXTAL	sys	I	--	--	--	EXTAL	X'tal		System clock input. Connected to 20MHz X'tal.
67	XTAL	sys	I	--	--	--	XTAL	X'tal		System clock output. Connected to 20MHz X'tal.
68	Vcc	sys	--	--	--	--	VCC			Connected to the system power supply (+5V).
69	PA63	I/O	O	--	Low	--	SIF_CK	74HC4094	CK	Serial clock data output for ports expand IC.
70	PA64	I/O	O	--	Low	--	DAC_DATA	PCM1710	MD/DM1	Serial data output for D/A converter IC.
71	PA65	I/O	O	--	Low	--	DAC_CLK	PCM1710	MC/DM2	Serial clock data output for D/A converter IC.
72	PA66	I/O	O	--	Low	--	DAC_LAT	PCM1710	ML/DSD	Serial latch data output for D/A converter IC.

PIN No.	PORT NAME	DEV ICE I/O	I/O	ACTIVE	INITIAL	PULL UP/DOWN	SIGNAL NAME	CONNECT DEVICE NAME	CONNECT DEVICE PORT	FUNCTION
73	MD0	sys	I	--	High	EXT_UP	MD0			Mode select input for MPU. Mode7 "H".
74	MD1	sys	I	--	High	EXT_UP	MD1			Mode select input for MPU. Mode7 "H".
75	MD2	sys	I	--	High	EXT_UP	MD2			Mode select input for MPU. Mode7 "H", FLASH MPU program "L".
76	Avcc	sys	I	--	--	--	AVCC			Connected to the system power supply (+5V).
77	Vref	sys	I	--	--	--	VREF			Ditto.
78	P70 /AN0	I	I	Low	High	EXT_UP	SW_SP0	KEY INPUT		PLAY/PAUSE button input. Active "L".
79	P71/AN1	I	I	Low	High	EXT_UP	SW_SP1	KEY INPUT		CUE button input. Active "L".
80	P72/AN2	I	I	Low	High	EXT_UP	SW_FADER	KEY INPUT		FADER SW input. Active "L".
81	P73/AN3	I	I	--	High	EXT UP	EEPROM_SO	AT25640	SO	Serial data input for EEPROM.
82	P74/AN4	I	I	--	Low	EXT_UP	TRAY_SW_OPEN	TRAY OPEN SW		Tray Open SW input. Open "L".
83	P75/AN5	I	I	--	Low	EXT_UP	TRAY_SW_CLOSE	TRAY CLOSE SW		Tray Close SW input. Close "L".
84	P76 /AN6/DA0	I	I	--	Low	UP/DW	SYS_MODEL_SEL0	RU09,RU05		(SEL0,SEL1): PMD330=(0,0), PMD331=(0,1) PMD340=(1,0)
85	P77 /AN7/DA1	I	I	--	Low	UP/DW	SYS_MODEL_SEL1	RU10,RU11		
86	Avss	sys	I	--	Low	--	AVSS			Connected to the system power supply (0V).
87	P80 /IRQ0/	I/O	I	--	Low	--	CXD_SCOR	CXD2585Q	SCOR	Detected from Sub code think signal. Detected "H".
88	P81 /IRQ1/	I/O	O	Low	High	EXT_UP	MONI_MUTE			Audio pre-mute control output. MUTE "L".
89	P82 /IRQ2/	I/O	O	High	Low	EXT_UP	TRAY_DRV_OPEN	LB1641	IN2	(IN1,IN2), (1,0) CW LOAD, (0,1) CCW UNLOAD, (0,0) or (1,1) STOP
90	P83 /IRQ3/	I/O	O	High	Low	EXT_UP	TRAY_DRV_CLOSE	LB1641	IN1	
91	P84	I/O	O	Low	Low	--	AUDIO_MUTE			Audio mute control output. MUTE "L".
92	Vss	sys	--	--	--	--	VSS			Connected to the system power supply (0V).
93	PA0 /TP0/TCLKA	I/O	I	Low	High	EXT_DW	ROT_DIAL_A	DIAL(+)		Rotary encoder input. CW (Forward) "H", CCW (Reverse) "L". 24puls/360°
94	PA1 /TP1/TCLKB	I/O	I	Low	High	EXT_DW	ROT_DIAL_B	DIAL(-)		
95	PA2 /TP2/TIOCA0	I/O	O	Low	High	--	RC5_MASK			IR signal mask SW.
96	PA3 /TP3/TIOCB0	I/O	O	--	Low	--	RC5_OUTPUT			RC5 signal output.
97	PA4 /TP4/TIOCA1	I/O	I	--	Low	--	RC5_INPUT	SPS-446-4		RC5 signal input.
98	PA5 /TP5/TIOCB1	I/O	O	High	High	EXT_UP	EEPROM_CS	AT25640	CS	Chip select output for EEPROM. Enable "H", Disable "L".
99	PA6 /TP6/TIOCA2	I/O	O	--	High	EXT_UP	EEPROM_SI	AT25640	SI	Serial data input for EEPROM.
100	PA7 /TP7/TIOCB2	I/O	O	--	High	EXT_UP	EEPROM_CLK	AT25640	SCK	Serial clock data output for EEPROM.


QY01 : HD66712




Q201/Q202 : TDA7073A

PIN	SYMBOL	DESCRIPTION
1	IN1-	negative input 1
2	IN1+	positive input 1
3	n.c.	not connected
4	n.c.	not connected
5	VP	positive supply voltage
6	IN2+	positive input 2
7	IN2-	negative input 2
8	n.c.	not connected
9	OUT2+	positive output 2
10	GND2	ground 2
11	n.c.	not connected
12	OUT2-	negative output 2
13	OUT1-	negative output 1
14	GND1	ground 1
15	n.c.	not connected
16	OUT1+	positive output 1


QU03 : AT2560



Pin Name	Function
CS	Chip Select
SCK	Serial Data Clock
SI	Serial Data Input
SO	Serial Data Output
GND	Ground
VCC	Power Supply
WP	Write Protect
HOLD	Suspends Serial Input
NC	No Connect
DC	Don't Connect



QD01 : CXD2585Q




Pin No.	Symbol	I/O	Description
1	DVDD0	-	Power supply.
2	XRST	I	System reset. Reset when low.
3	MUTE	I	Mute input (low: off, high: on)
4	DATA	I	Serial data input from CPU.
5	XLAT	I	Latch input from CPU. Serial data is latched at the falling edge.
6	CLOCK	I	Serial data transfer clock input from CPU.
7	SENS	O 1, 0	SENS output to CPU.
8	SCLK	I	SENS serial data readout clock input.
9	ATSK	I/O 1, 0	Anti-shock input/output.
10	WFCK	O 1, 0	WFCK output.
11	XUGF	O 1, 0	XUGF output. MNT0 or RFCK is output by switching with the command.
12	XPCK	O 1, 0	XPCK output. MNT1 is output by switching with the command.
13	GFS	O 1, 0	GFS output. MNT2 or XROF is output by switching with the command.
14	C2PO	O 1, 0	C2P0 output. MNT3 or GTOP is output by switching with the command.
15	SCOR	O 1, 0	Outputs a high signal when either subcode sync S0 or S1 is detected.
16	C4M	O 1, 0	4.2336MHz output. 1/4 frequency division output for V16M in CAV-W mode or variable pitch mode.
17	WDCK	O 1, 0	Word clock output. f = 2Fs. GRSCOR is output by the command switching.
18	DVss0	- -	Digital GND.
19	COUT	I/O 1, 0	Track count ,signal I/O.
20	MIRR	I/O 1, 0	Mirror signal I/O.
21	DFCT	I/O 1, 0	Detect signal I/O.
22	FOK	I/O 1, 0	Focus OK signal I/O.
23	PWMI	I	Spindle motor external control input.
24	LOCK	I/O 1, 0	GFS is sampled at 460Hz; when GFS is high, this pin outputs a high signal. If GFS is low eight consecutive samples, this pin outputs low. Input when LKIN=1.
25	MDP	O 1, Z, 0	Spindle motor servo control output.
26	SSTP	I	Disc innermost track detection signal input.
27	FSTO	O 1, 0	2/3 frequency division output for XTAI pin.
28	DVDD1	- -	Digital power supply.
29	SFDR	O 1, 0	Sled drive output.
30	SRDR	O 1, 0	Sled drive output.
31	TFDR	O 1, 0	Tracking drive output.
32	TRDR	O 1, 0	Tracking drive output.
33	FFDR	O 1, 0	Focus drive output.
34	FRDR	O 1, 0	Focus drive output.
35	DVss1	- -	Digital GND.
36	TEST	I	Test. Normally, GND.

Pin NO.	Symbol	I/O	Description
37	TES1	I	Test. Normally, GND.
38	VC	I	Center voltage input.
39	FE	I	Focus error signal input.
40	SE	I	Sled error signal input.
41	TE	I	Tracking error signal input.
42	CE	I	Center servo analog input.
43	RFDC	I	RF signal input.
44	ADIO	O Analog	Test. No connected.
45	AVss0	- -	Analog GND.
46	IGEN	I	Constant current input for operational amplifier.
47	AVDD0		Analog power supply.
48	ASYO	O 1, 0	EFM full-swing output. (low = Vss, high = VDD)
49	ASYI	I	Asymmetry comparator voltage input.
50	RFAC	I	EFM signal input.
51	AVss1	- -	Analog GND.
52	CLTV	I	Multiplier VCO1 control voltage input.
53	FILO	O Analog	Master PLL filter output (slave = digital PLL).
54	FILI	I	Master PLL filter input.
55	PCO	O 1, Z, 0	Master PLL charge pump output.
56	AVDD1	- -	Analog power supply.
57	BIAS	I	Asymmetry circuit constant current input.
58	VCTL	I	Wide-band EFM PLL VC02 control voltage input.
59	V16M	I/O 1, 0	Wide-band EFM PLL VC02 oscillation output. Serves as wide-band EFM PLL clock input by switching with the command.
60	VPCO	O 1, Z, 0	Wide-band EFM PLL charge pump output.
61	DVDD2	- -	Digital power supply.
62	ASYE	I	Asymmetry circuit on/off (low = off, high = on).
63	MD2	I	Digital Out on/off control (low = off, high = on).
64	DOUT	O 1, 0	Digital Out output.
65	LRCK	O 1, 0	D/A interface. LR clock output. f = Fs
66	PCMD	O 1, 0	D/A interface. Serial data output (two's complement, MSB first).
67	BCK	O 1, 0	D/A interface. Bit clock output.
68	EMPH	O 1, 0	Outputs a high signal when the playback disc has emphasis, and a low signal when there is no emphasis.
69	XTSL	I	Crystal selection input. Low when the crystal is 16.9344MHz; high when it is 33.8688MHZ.
70	DVss2	- -	Digital GND.
71	XTAI	I	Crystal oscillation circuit input. When the master clock is input externally, input it from this pin.
72	XTAO	O	Crystal oscillation circuit output.


Pin NO.	Symbol	I/O	Description
73	SOUT	O 1, 0	Serial data output in servo block.
74	SOCK	O 1, 0	Serial data readout clock output in servo block.
75	XOLT	O 1, 0	Serial data latch output in servo block.
76	SQSO	O 1, 0	Sub-Q 80-bit, PCM peak or level data outputs. CD TEXT data output t.
77	SQCK	I	SQSO readout clock input.
78	SCSY	I	GRSCOR resynchronization input.
79	SBSO	O 1, 0	Sub-Q P to W serial output.
80	EXCK	I	SBSO readout clock input.

Notes)  
\* PCMD is a MSB first, two's complement output.  
\* GTOP is used to monitor the frame sync protection status. (High: sync protection window released.)  
\* XUGF is the frame sync obtained from the EFM signal, and is negative pulse. It is the signal before sync protection.  
\* XPCK is the inverse of the EFM PLL clock. The PLL is designed so that the falling edge and the EFM signal Atransition point coincide.  
\* The GFS signal goes high when the frame sync and the insertion protection timing match.  
\* RFCK is derived from the crystal accuracy, and has a cycle of 136us. (during normal speed)  
\* C2PO represents the data error status.  
\* XROF is generated when the 32K RAM exceeds the +-28F jitter margin.

QT52 : SN75158




Q501 : PCM1710




PIN NAME	NUMBER	FUNCTION
<b>Input Interface Pins</b>		
LRCIN	1	Sample Rate Clock Input. Controls the update rate (fs).
DIN	2	Serial Data Input. MSB first, right justified format contains a frame of 16-bit or 20-bit data.
BCKIN	3	Bit Clock Input. Clocks in the data present on DIN input.
<b>Mode Controls and Clock Signals</b>		
CLKO	4	Buffered Output of Oscillator. Equivalent to fs.
XTI	5	Oscillator Input (External Clock Input). For an internal clock, tie XTI to one side of the crystal oscillator. For an external clock, tie XTI to the output of the chosen external clock.
XTO	6	Oscillator Output. When using the internal clock, tie to the opposite side (from pin 5) of the crystal oscillator. When using an external clock, leave XTO open.
CKSL	23	System Clock Select. For 384fs, tie CKSL "High". For 256fs, tie CKSL "Low".
MODE	24	Operation Mode Select. For serial mode, tie MODE "High". For parallel mode, tie MODE "Low".
MUTE	25	Mute Control. To disable soft mute, tie MUTE "High". To enable soft mute, tie MUTE "Low".
MD/DM1	26	Mode Control for Data/De-emphasis. See "Mode Control Functions" on page 11.
MC/DM2	27	Mode Control for BCKIN/De-emphasis. See "Mode Control Functions" on page 11.
ML/DSD	28	Mode Control for WDCK/Double speed dubbing. See "Mode Control Functions" on page 11.
<b>Analog Functions</b>		
V <sub>OUTR</sub>	13	Right Channel Analog Output.
V <sub>OUTL</sub>	16	Left Channel Analog Output.
<b>Power Supply Connections</b>		
DGND	7, 22	Digital Ground.
V <sub>DD</sub>	8, 21	Digital Power Supply (+5V).
V <sub>CC2R</sub>	9	Analog Power Supply (+5V), Right Channel DAC.
AGND2R	10	Analog Ground (DAC), Right Channel.
EXT1R	11	Output Amplifier Common, Right Channel. Bypass to ground with a 10μF capacitor.
EXT2R	12	Output Amplifier Bias, Right Channel. Connect to EXT1R.
AGND	14	Analog Ground.
V <sub>CC</sub>	15	Analog Power Supply (+5V).
EXT2L	17	Output Amplifier Bias, Left Channel. Connect to EXT1L.
EXT1L	18	Output Amplifier Common, Left Channel. Bypass to ground with a 10μF capacitor.
AGND2L	19	Analog Ground (DAC), Left Channel.
V <sub>CC2L</sub>	20	Analog Power Supply (+5V), Left Channel DAC.

Q101 : TZA1022




SYMBOL	PIN	DESCRIPTION
OD2	1	output photo diode amplifier 2
OD3	2	output photo diode amplifier 3
OD4	3	output photo diode amplifier 4
OD5	4	output photo diode amplifier 5
OD1	5	output photo diode amplifier 1
PWRON	6	power on switch
RF	7	output data signal
V <sub>DDRF</sub>	8	RF amplifier supply voltage
V <sub>DD</sub>	9	supply voltage
GND	10	ground
GND <sub>RF</sub>	11	ground RF amplifier
V <sub>DDL</sub>	12	laser supply voltage
LO	13	current output for the laser diode
MI	14	Monitor input
n.c.	15	not connected
n.c.	16	not connected
AP1S	17	Input photo diode amplifier (satellite)
AP2C	18	Input photo diode amplifier (central)
n.c.	19	not connected
FTC	20	output fast track counting
LG	21	CD/CDRW gain switch
AP3C	22	Input photo diode amplifier (central)
AP5S	23	Input photo diode amplifier (satellite)
AP4C	24	Input photo diode amplifier (central)

Q251 : BA6856FP




PIN No	端子名 /Pin Name	機能 /Function
1	N.C.	N.C.
2	N.C.	N.C.
3	A <sub>2</sub>	出力端子/Output3 for motor
4	N.C.	N.C.
5	A <sub>2</sub>	出力端子/Output2 for motor
6	N.C.	N.C.
7	A <sub>1</sub>	出力端子/Output1 for motor
8	GND	GND端子/GND
9	H <sub>1</sub> <sup>+</sup>	ホール信号入力端子/Hall input Amp1. positive input
10	H <sub>1</sub> <sup>-</sup>	ホール信号入力端子/Hall input Amp1. negative input
11	H <sub>2</sub> <sup>+</sup>	ホール信号入力端子/Hall input Amp2. positive input
12	H <sub>2</sub> <sup>-</sup>	ホール信号入力端子/Hall input Amp2. negative input
13	H <sub>3</sub> <sup>+</sup>	ホール信号入力端子/Hall input Amp3. positive input
14	H <sub>3</sub> <sup>-</sup>	ホール信号入力端子/Hall input Amp3. negative input
15	N.C.	N.C.
16	FG3	FG信号出力端子/FG3 signal output terminal
17	FG2	FG信号出力端子/FG2 signal output terminal
18	FG1	FG信号出力端子/FG1 signal output terminal
19	V <sub>H</sub>	ホール/バイアス端子/Hall Bias
20	C <sub>HF</sub>	位相補償用コンデンサ接続端子 /Capacitor connection pin for phase compensation
21	E <sub>CR</sub>	出力電圧制御基準端子 /Torque control standard voltage input terminal
22	E <sub>C</sub>	出力電圧制御端子/Torque control voltage input terminal
23	PS	パワーセーブ端子/ POWER SAVE switch
24	R <sub>REV</sub>	逆転端子/Reverse terminal
25	V <sub>CC</sub>	電源端子/Power supply for signal division
26	V <sub>M2</sub>	12V用電源端子/Power supply2 for driver
27	V <sub>M1</sub>	モータ電源端子/Power supply1 for driver
28	R <sub>HF</sub>	出力電流検出用抵抗接続端子 /Power supply for driver division
FIN	FIN	GND

Q301 : RL5C357




Pin	PIN NAME	I/O	FUNCTION	LOGIC	
				H	L
1	VCC	--	POWER SUPPLY	--	--
2	XQOK	Ipu	SUB CODE-Q OK SIGNAL FROM CPU	--	OK
3	XWRE	Ipu	WRITE ENABLE SIGNAL FROM CPU	--	PERMIT
4	XEMP	O	READ INHIBIT SIGNAL TO CPU	--	INHIBIT
5	XWIH	O	WRITE INHIBIT SIGNAL TO CPU	--	INHIBIT
6	XCAS2	O	DRAM CAS2 CONTROL	--	--
7	CHDT	O	DATA COMPARATIVE MONITOR SIGNAL OUTPUT TO CPU	COMPARE	--
8	A10	O	DRAM ADDRESS 10	--	--
9	CLK	I	16.9344MHz CLOCK INPUT	--	--
10	GND	--	GROUND	--	--
11	DATI	Ics	AUDIO DATA INPUT	--	--
12	LRCI	Ics	AUDIO L/R CLOCK INPUT	Lch	Rch
13	BCKI	Ics	AUDIO BIT CLOCK INPUT	--	--
14	BCKO	O	AUDIO BIT CLOCK OUTPUT	--	--
15	LRCO	O	AUDIO L/R CLOCK OUTPUT	Lch	Rch
16	DATO	O	AUDIO DATA OUTPUT	--	--
17	XROF	Ics	RAM OVERFLOW FROM SIGNAL PROCESSOR IC	--	OVER FLOW
18	RFCK	Ipu	FRAME CLOCK FROM SIGNAL PROCESSOR IC, DERIVED FROM THE CRYSTAL ACCURACY	--	--
19	SCOR	I	SUB CODE SYNC DETECT SIGNAL FROM SIGNAL PROCESSOR IC	--	--
20	XRST	Ics	SYSTEM RESET	--	RESET
21	SDTO	O	SERIAL DATA OUTPUT TO CPU	--	--
22	XSOE	Ipu	SERIAL DATA OUTPUT PERMISSION SIGNAL INPUT FROM CPU	--	PERMIT
23	TEST	Ipd	TEST MODE	--	--
24	XLT	Ics	LATCH INPUT FROM CPU	--	--
25	SDTI	Ics	SERIAL DATA INPUT FROM CPU	--	--
26	SCK	Ics	SERIAL DATA TRANSFER CLOCK INPUT FROM CPU	--	--
27	XCAS1/XOE	O	DRAM CAS1/OE CONTROL	--	--
28	XCAS0	O	DRAM CAS0 CONTROL	--	--
29	D2	I/O	DRAM DATA 2	--	--
30	D3	I/O	DRAM DATA 3	--	--
31	D0	I/O	DRAM DATA 0	--	--
32	D1	I/O	DRAM DATA 1	--	--
33	XWE	O	DRAM WE CONTROL	--	--
34	XRAS	O	DRAM RAS CONTROL	--	--
35	A9	O	DRAM ADDRESS 9		
36	A8	O	DRAM ADDRESS 8		
37	A7	O	DRAM ADDRESS 7		
38	A6	O	DRAM ADDRESS 6		
39	A5	O	DRAM ADDRESS 5		
40	A4	O	DRAM ADDRESS 4		
41	A0	O	DRAM ADDRESS 0		
42	A1	O	DRAM ADDRESS 1		
43	A2	O	DRAM ADDRESS 2		
44	A3	O	DRAM ADDRESS 3		

Q302 : HY5117400BJ-60




QU57 QU58 : 74HC165




PIN NUMBER	SYMBOL	FUNCTION
1	PL	Asynchronous parallel load input (active LOW)
2	CP	Clock input (LOW to HIGH, edge-triggered)
7	$\overline{Q}_7$	Complementary output from the last stage
8	GND	Ground (0 V)
9	$Q_7$	Serial output from last stage
10	D <sub>S</sub>	Serial data input
11, 12, 13, 14, 3, 4, 5, 6	D <sub>0</sub> to D <sub>7</sub>	Parallel data inputs
15	$\overline{CE}$	Clock enable input (active LOW)
16	V <sub>CC</sub>	Positive supply voltage

QU04 QU56 : 74HC4094


PIN NO.	SYMBOL	NAME AND FUNCTION
1	STR	strobe input
2	D	serial input
3	CP	clock input
4, 5, 6, 7, 14, 13, 12, 11	Q <sub>P0</sub> to Q <sub>P7</sub>	parallel outputs
8	GND	ground (0 V)
9, 10	Q <sub>S1</sub> , Q <sub>S2</sub>	serial outputs
15	OE	output enable input
16	V <sub>CC</sub>	positive supply voltage




## 6. WIRING DIAGRAM



## 7. BLOCK DIAGRAM



8. SCHEMATIC DIAGRAM










# PMD330, PMD331 ONLY





	Q102	R101	R102	R103	R104	R105	C101	C102	C103	C104	C105	C106	C107	C108	C109	C110	C111	C112	C113	C114	C115	C116	C117	C118
PMD330	NAI2100M	—	0	0	—	0	—	—	10p	2p	—	—	—	—	—	—	—	—	—	—	—	—	—	—
PMD331	NAI2100M	880	880	—	0	—	27p	220p	27p	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—


  

	Q203	R216	R217	C201	C214	Q204	R210	R212	R213	C218
PMD330	—	0	8.2k	4700p	0.47	—	22k	1k	—	—
PMD331	10k TH	12k	15k	1000p	0.22	TC4558P	0	4.7k	1k	0.1

# PMD340 ONLY



PY01





PD01

Q301 Q302  
Q501 Q541  
Q502

QB03 QB02  
QB01

QB04

QU41 QU42

QU91

QU04

QU01

QD01

QU03  
QU52 QU51


Q802 Q801  
Q804

Q803  
Q806 Q805

QM01

QU58 QU57  
QU64 QU63 QU62


QU56  
Q61 QU60 QU59






P101 (PMD330, PMD331)

Q110 Q108 Q112  
Q107 Q106 Q103 Q102




P101 (PMD340)


Q110 Q108 Q112  
Q107 Q106 Q103 Q102



P851



P801



10. EXPLODED VIEW AND PARTS LIST

POS. NO	VERS. COLOR	PART NO. (FOR PCS)	DESCRIPTION	PART NO. (MJI)	POS. NO	VERS. COLOR	PART NO. (FOR PCS)	DESCRIPTION	PART NO. (MJI)
001B	BLACK		FRONT PANEL PMD330 BLK	371K248010	062G			STICKER	***
001B	GRAY	9965 000 01604	FRONT PANEL PMD330 GRAY	371K248020	092G			INNER LASER CAUTION	***
001B	BLACK		FRONT PANEL PMD331 BLK	371K248110	094G			LABEL LASER CAUTION	***
001B	GRAY	9965 000 01726	FRONT PANEL PMD331 GRAY	371K248120	901G			REAR PANEL	***
001B	BLACK		FRONT PANEL PMD340 BLK	371K248210	907G			LABEL	***
001B	GRAY	9965 000 01721	FRONT PANEL PMD340 GRAY	371K248220	909G			B.H. TAP. SCREW	***
					911G			PH.TAP.SCREW	***
003B	BLACK		FRONT CHASSIS PMD330 BLK	371K105020					
003B	GRAY	9965 000 01605	FRONT CHASSIS PMD330 GRAY	371K105030	001M		9965 000 01625	NEW LOADER LM302 OLD TRAY BLK	305K304680
003B	BLACK		FRONT CHASSIS BLACK PMD331/N,U, PMD340/N	371K105040	005M		4822 464 10054	FRAME K	305K401500
003B	GRAY	9965 000 01722	FRONT CHASSIS PMD331/340 GRAY	371K105050	010M		4822 361 21741	MOTOR	MM0030002R
003B	340/U		FRONT CHASSIS PMD340 USA BLACK	371K105060	015M		4822 321 63208	CABLE	YB00380590
					016M		4822 271 30873	MINI SWITCH	SM01020620
005B	BLACK		WINDOW BLK	371K158010	020M		4822 522 33521	GEAR	305K058030
005B	GRAY	9965 000 01606	WINDOW GRAY	371K158020	021M		4822 528 81537	PULLEY	305K262010
006B		9965 000 01607	IR LENS	371K355020	025M		4822 522 33522	GEAR K	305K058500
007B	BLACK		ESCUTCHEON	292K063220	030M		4822 358 31325	BELT	305K264010
007B	340/U		ESCUTCHEON PMD340 USA	292K063260	031M		4822 459 50976	MASK	305K303010
007B	GRAY	9965 000 01608	ESCUTCHEON	292K063230	035M		4822 443 51265	CASE	305K064110
009B	BLACK		POWER BUTTON	371K270150	036M		9965 000 01626	SUSPENSION	371K056010
009B	GRAY	9965 000 01609	POWER BUTTON	371K270160	040M		4822 402 11212	NEW LIFT ARM	305K002050
010B	BLACK		BUTTON	371K270170	043M		9965 000 00234	CASE K NEW GEAR/OLD TRAY	305K064600
010B	GRAY	9965 000 01610	BUTTON	371K270180	045M			CASE BLACK	305K064010
011B			LCD SHEET	***	046M			SPRING	305K115010
012B	BLACK		ROTARY KNOB PMD331/340 BLACK	372K154010	050M			CAM	305K054010
012B	GRAY	9965 000 01723	ROTARY KNOB PMD331/340 GRAY	372K154020	051M			NEW SLIDER GEAR	305K058050
013B			LCD SPACER	***	060M		4822 492 33495	SPRING	305K115020
015B			LCD HOLDER	***	501M	330,331	9965 000 01627	MECHANISM VAM 1202	371K304500
016B			INSULATOR FOR 015B	***			9305 022 20200		
017B			LCD REFLECTOR	***	501M	340	9965 000 01724	MECHANISM VAM 1250	374K304500
019B			LCD LENS	***			9305 022 25001	BRACKET	***
020B			WEIGHT FOR KNOB	***	510M			STOPPER FOR DISC	371K114010
021B			BRACKET FOR PHONE JACK	***	518M			STOPPER FOR DISC	371K114020
023B	BLACK		KNOB FOR PHONE VOLUME	284T154310	520M			ADHESIVE FOR 520M	371K122010
023B	GRAY	9965 000 01611	KNOB FOR PHONE VOLUME	284T154050	522M			CLAMPER ASSY VAM1202	371K005500
027B		9965 000 01612	BUTTON RUBBER	371K270010	555M	330,331		CLAMPER ASSY VAM1250	374K005500
029B		9965 000 01614	BUTTON MODE KEY	371K270020					
031B		9965 000 01615	BUTTON END KEY	371K270030	▲ J001	/F	9965 000 01313	JACK 2P AC INLET M1910-H	YJ04002440
033B		9965 000 01616	BUTTON A-B KEY	371K270040	▲ J001	/N	9965 000 01313	JACK 2P AC INLET M1910-H	YJ04002440
035B		9965 000 01617	BUTTON PITCH KEY	371K270050	▲ J001	/U		JACK 3P AC INLET M1910-D	YJ04002450
037B		9965 000 01618	BUTTON +/- KEY	371K270070					
039B		9965 000 01619	BUTTON NEXT/PREV KEY	371K270080	W051		9965 000 01602	JUMPER LEAD 20P FFC	YU20170500
041B		9965 000 01620	BUTTON FF/FR KEY	371K270090	W052		9965 000 01603	JUMPER LEAD 30P FFC	YU30170520
043B		9965 000 01621	BUTTON STOP KEY	371K270100	W053	331,340		JUMPER LEAD 5P FPC	YU05090500
045B		9965 000 01622	BUTTON CUE KEY	371K270110	W054	331,340		JUMPER LEAD 5P FPC	YU05090500
047B		9965 000 01623	BUTTON PLAY KEY	371K270120					
001D	/U1B		LID TOP COVER BLACK	292J257030	001T	/F		USER MANUAL	371K851110
003D	/U1B		MOUNT BRACKET L	371K160040	001T	/N	9965 000 01628	USER MANUAL	371K851310
005D	/U1B		MOUNT BRACKET R	371K160050	001T	/U		USER MANUAL	371K851250
001G			CHASSIS	***	▲ W001	/F		MAINS CORD 2P 12A 125V	ZC02001180
003G			SIDE BRACKET L	***	▲ W001	330/N	4822 321 11439	MAINS CORD 2P 10A 250V	ZC01803080
007G			SIDE BRACKET R	***		331/N		CLASS2	
011G		9965 000 01624	LEG BLACK	371K057010	▲ W001	340/N	4822	MAINS CORD 3P 10A 250V	ZC02003180
012G			BUFFER FOR LEG	371K056020				CLASS1	
015G			LOADER BRACKET	***	▲ W001	/U		MAINS CORD 3P 10A 125V	ZC02002180
026G			BRACKET FOR PD01	***					
030G			SUPPORT FOR PD01	***					
031G			SUPPORT FOR P801	***	001S	330		PACKING CASE PMD330	371K801010
037G		4822 402 10913	LINK	318K121010	001S	331		PACKING CASE PMD331	372K801010
039G	/U		SCREW FOR GND	***	001S	340		PACKING CASE PMD340	374K801010
045G			LABEL FOR GND	***	003S			CUSHION	371K809010
060G			SHEET	***	W004	/U		AUDIO CABLE	ZD01000330

NOTE : \*\*\* =PART IS LISTED FOR REFERENCE ONLY, MARANTZ WILL NOT SUPPLY THESE PARTS.





11. TECHNICAL DESCRIPTION

1. RC5 Code

This product is able to communicate to the other MARANTZ products with the RCA Pin cable.

1. RC5コード

RCA Pinコードを介して他の機器と通信できる。

	Command Name	Code	Decode			Binary			
			SYS	COM	DATA	START	SYS	COM	DATA
INPUT	Play	2053	20	53		11	10100	110101	
	Pause	2048	20	48		11	10100	110000	
	Cue	2059-10	20	59	10	11	10100	111011	1010
	Stop	2054	20	54		11	10100	110110	
	FF	2052	20	52		11	10100	110100	
	FR(REW)	2050	20	50		11	10100	110010	
	Index+	2034	20	34		11	10100	100010	
	Index-	2035	20	35		11	10100	100011	
	Next	2032	20	32		11	10100	100000	
	Previous	2033	20	33		11	10100	100001	
	Pitch+	2038	20	38		11	10100	100110	
	Pitch-	2039	20	39		11	10100	100111	
	Pitch Bend+ ★ 2 ★ 3	2038-10	20	38	10	11	10100	100110	1010
	Pitch Bend- ★ 2 ★ 3	2039-10	20	39	10	11	10100	100111	1010
	A-B	2059	20	59		11	10111	111011	
	Program	2041	20	41		11	10100	101001	
	Pitch On/Off	2037	20	37		11	1010	100101	
	Open/Close	2045	20	45		11	10100	101101	
	Time	2011	20	11		11	10100	1011	
	Mode	2036-10	20	36	10	11	10100	100100	1010
	Preset	2041-12	20	41	12	11	10100	101001	1100
	END monitor	2043-10	20	43	10	11	10100	101011	1010
	CD-TEXT	2088	20	88		10	10100	11000	
	0	2000	20	00		11	10100	0	
	1	2001	20	01		11	10100	1	
	2	2002	20	02		11	10100	10	
	3	2003	20	03		11	10100	11	
	4	2004	20	04		11	10100	100	
	5	2005	20	05		11	10100	101	
	6	2006	20	06		11	10100	110	
	7	2007	20	07		11	10100	111	
	8	2008	20	08		11	10100	1000	
	9	2009	20	09		11	10100	1001	
	SERVICE ★1	166363	16	63	63	11	10000	111111	111111
OUTPUT	Connect	1856	18	56		11	10010	111000	
	Disconnect	1857	18	57		11	10010	111001	

\*1 The service code is available during STOP mode only.

\*2 The Pitch Bend+ and Pitch Bend- are not available with the digital out on.

\*3 The Pitch Bend+ and Pitch Bend- are not available on PMD330.

\*1 サービスコードは STOP 状態の時のみ受け付ける。

\*2 Pitch Bend+、Pitch Bend- はデジタルアウト On 時には受け付けない。

\*3 表内の Pitch Bend+、Pitch Bend- は PMD330 では No Action とする。

5. GPI code

The GPI code is input from external controller with D-Sub 25 Pin connector.

2. GPI コード

D-Sub25Pinコネクタで外部のコントローラーより入力される。

Pin	Name	I/O	Active
1	PLAY TALLY	O	Low
2	PAUSE TALLY	O	Low
3	CUE TALLY	O	Low
4	STOP	I	Low
5	FR	I	Low
6	INDEX-	I	Low
7	PREVIOUS	I	Low
8	PITCH+	I	Low
9	PITCH ON/OFF	I	Low
10	FADER(NORMAL)	I	Low
11	INDEX #2/#3 TALLY	O	Low
12	+5V	-	---
13	FG COMMON	-	---
14	PLAY	I	Low
15	PAUSE	I	Low
16	CUE	I	Low
17	FF	I	Low
18	INDEX+	I	Low
19	NEXT	I	Low
20	END	I	Low
21	PITCH-	I	Low
22	FADER TALLY	O	Low
23	FADER(INVERT)	I	High
24	END TALLY	O	Low
25	TALLY COMMON	-	---

\* The fader start is on during PLAY, and off during PAUSE.

\* The index is output by pulse signal.

When the index #2 is selected, the pulse signal of 200ms is output at the top of index #2.

1 1 1 1 2 2 2 2 2 2 2  
-----  
200ms

When the index #3 is selected, the pulse signal of 200ms is output at the top of index #3.

2 2 2 2 3 3 3 3 3 3 3  
-----  
200ms

3. Double speed Reading

The disc (spindle) motor of PMD331/340 rotates at double speed for the Instant start & Anti-shock (shockproof) behavior function.

The data that is read out at double speed from a CD is put into the shockproof memory control & DRAM.

The data that is in the shockproof memory is forwarded to the DAC and is played back at normal speed.

When it is set Digital Out to "ON" on the preset menu, the disc (spindle) motor rotates at normal speed, and the data is read at normal speed.

Therefore, Digital output is always outputted at normal speed.

PMD330 doesn't have the shockproof memory control. Therefore the disc (spindle) motor of PMD330 always rotates at normal speed.

※ Fader Start は、Play で On し、Pause 状態で Off となる。

※ Index はパルスで出力する。

Index #2 選択時、Index #2 の頭で 200ms のパルスを出力する。

1 1 1 1 2 2 2 2 2 2 2  
-----  
200ms

Index #3 選択時、Index #3 の頭で 200ms のパルスを出力する。

2 2 2 2 3 3 3 3 3 3 3  
-----  
200ms

3. 2倍速について

PMD331/340は、Instant start & Anti-shock (shokproof) behavior 機能の為に、2倍速で Disc (Spindle) Motor を回転させています。

CD から 2倍速にて読み出されたデータは、Shokproof memory control & DRAM にいったんメモリーします。

ここでメモリーされたデータは 1倍速にて Shokproof memory control より DAC に転送され通常のスピードで再生されます。

但し、Preset Menu にて Digital Out "ON" に設定した場合は、1倍速で Disk (Spindle) Motor は回転し 1倍速でデーターの読み出しが行われます。

よって、Digital 出力は常に 1倍速で出力されます。

PMD330 は Shokproof memory control を搭載していないので常に Disc (Spindle) Motor は 1倍速にて回転します。

## 12. ELECTRICAL PARTS LIST

### ASSIGNMENT OF COMMON PARTS CODES.

#### RESISTORS

R\*\*\*: 1) GD05 × × × 140, Carbon film fixed resistor, ±5% 1/4W  
 R\*\*\*: 2) GD05 × × × 160, Carbon film fixed resistor, ±5% 1/6W

① — Resistance value

Examples ;

① Resistance value

0.1 Ω .... 001    10 Ω .... 100    1 kΩ .... 102    100 kΩ .... 104  
 0.5 Ω .... 005    18 Ω .... 180    2.7 kΩ .... 272    680 kΩ .... 684  
 1 Ω .... 010    100 Ω .... 101    10 kΩ .... 103    1 MΩ .... 105  
 6.8 Ω .... 068    390 Ω .... 391    22 kΩ .... 223    4.7 MΩ .... 475

**Note :** Please distinguish 1/4W from 1/6W by the shape of parts used actually.

#### CAPACITORS

C\*\*\*: CERAMIC CAP.

3) DD1 × × × × 370, Ceramic capacitor  
 Disc type  
 Temp.coef.P350 ~N1000, 50V  
 ② — Capacity value  
 ③ — Tolerance

Examples ;

② Tolerance (Capacity deviation)

±0.25 pF .... 0  
 ±0.5 pF .... 1  
 ±5% .... 5

\* Tolerance of COMMON PARTS handled here are as follows :

0.5 pF ~ 5 pF .... ±0.25 pF  
 6 pF ~ 10 pF .... ±0.5 pF  
 12 pF ~ 560 pF .... ±5%

③ Capacity value

0.5 pF .... 005    3 pF .... 030    100 pF .... 101  
 1 pF .... 010    10 pF .... 100    220 pF .... 221  
 1.5 pF .... 015    47 pF .... 470    560 pF .... 561

C\*\*\* : CERAMIC CAP.

4) DK16 × × × 300, High dielectric constant ceramic capacitor  
 Disc type  
 Temp.chara. 2B4, 50V  
 ④ — Capacity value

Examples ;

④ Capacity value

100 pF .... 101    1000 pF .... 102    10000 pF .... 103  
 470 pF .... 471    2200 pF .... 222

C\*\*\* : 5) ELECTROLY CAP. (  $\text{E}$  ), 6) FILM CAP. (  $\text{F}$  )

5) EA × × × × × 10, Electrolytic capacitor  
 One-way lead type, Tolerance ±20%  
 ⑤ — Working voltage  
 ⑥ — Capacity value

Examples ;

⑤ Capacity value

0.1 μF .... 104    4.7 μF .... 475    100 μF .... 107  
 0.33 μF .... 334    10 μF .... 106    330 μF .... 337  
 1 μF .... 105    22 μF .... 226    1100 μF .... 118  
 2200 μF .... 228

⑥ Working voltage

6.3V .... 006    25V .... 025  
 10V .... 010    35V .... 035  
 16V .... 016    50V .... 050

6) DF15 × × × 350 — Plastic film capacitor  
 DF15 × × × 310 — One-way type, Mylar ±5% 50V  
 DF16 × × × 310 — Plastic film capacitor  
 One-way type, Mylar ±10% 50V  
 ⑦ — Capacity value

Examples ;

⑦ Capacity value

0.001 μF (1000 pF) ..... 102    0.1 μF .... 104  
 0.0018 μF ..... 182    0.56 μF .... 564  
 0.01 μF ..... 103    1 μF .... 105  
 0.015 μF ..... 153

**NOTE :** 1) The above CODES ( R\*\*\*, R\*\*\*, C\*\*\*, C\*\*\* and C\*\*\* ) are omitted on the schematic diagram in some case.

2) On the occasion, be confirmed the common parts on the parts list.

3) Refer to "Common Parts List" for the other common parts (RI05, DD4, DK4).

### NOTE ON SAFETY FOR FUSIBLE RESISTOR :

The suppliers and their type numbers of fusible resistors are as follows;

1. KOA Corporation

Part No. (MJI)	Type No. (KOA)	Description
NH05 × × × 140	RF25S × × × × ΩJ	(±5% 1/4W)
NH05 × × × 120	RF50S × × × × ΩJ	(±5% 1/2W)
NH85 × × × 110	RF73B2A × × × × ΩJ	(±5% 1/10W)
NH95 × × × 140	RF73B2E × × × × ΩJ	(±5% 1/4W)

\* Resistance value    Resistance value (0.1 Ω - 10 kΩ)

2. Matsushita Electronic Components Co., Ltd

Part No. (MJI)	Type No. (MEC)	Description
NF05 × × × 140	ERD-2FCJ × × ×	(±5% 1/4W)
RF05 × × × 140		
NF02 × × × 140	ERD-2FCG × × ×	(±2% 1/4W)
RF02 × × × 140		

\* Resistance value    \* Resistance value

Examples ;

\* Resistance value

0.1 Ω .... 001    10 Ω .... 100    1 kΩ .... 102    100 kΩ .... 104  
 0.5 Ω .... 005    18 Ω .... 180    2.7 kΩ .... 272    680 kΩ .... 684  
 1 Ω .... 010    100 Ω .... 101    10 kΩ .... 103    1 MΩ .... 105  
 6.8 Ω .... 068    390 Ω .... 391    22 kΩ .... 223    4.7 MΩ .... 475

### ABBREVIATION AND MARKS

ANT. : ANTENNA	BATT. : BATTERY
CAP. : CAPACITOR	CER. : CERAMIC
CONN. : CONNECTING	DIG. : DIGITAL
HP : HEADPHONE	MIC. : MICROPHONE
μ-PRO : MICROPROCESSOR	REC. : RECORDING
RES. : RESISTOR	SPK : SPEAKER
SW : SWITCH	TRANSF : TRANSFORMER
TRIM. : TRIMMING	TRS. : TRANSISTOR
VAR. : VARIABLE	X'TAL : CRYSTAL

### NOTE ON SAFETY :

Symbol  $\Delta$  Fire or electrical shock hazard. Only original parts should be used to replaced any part marked with symbol  $\Delta$ . Any other component substitution (other than original type), may increase risk of fire or electrical shock hazard.

### 安全上の注意 :

$\Delta$  がついている部品は、安全上重要な部品です。必ず指定されている部品番号の部品を使用して下さい。

POS. NO	VERS. COLOR	PART NO. (FOR PCS)	DESCRIPTION	PART NO. (MJI)
<b>P101-SERVO CIRCUIT BOARD</b>				
<b>P101-CAPACITORS</b>				
C101	331/340	4822 126 11669	CER. CHIP 27pF ±5%	DD95270300
C102	331/340	4822 126 13883	CER. CHIP 220pF ±5% CG 50V	DD95221300
C103		4822 126 11669	CER. CHIP 27pF ±5%	DD95270300
C104		4822 126 14417	CER. CHIP 0.01μF ±10% 50V	DK96103300
C105		4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C106		4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C107		4822 122 31765	CER. CHIP 100pF ±5% CG 50V	DD95101300
C108		4822 122 31765	CER. CHIP 100pF ±5% CG 50V	DD95101300
C109		4822 126 14417	CER. CHIP 0.01μF ±10% 50V	DK96103300
C110		4822 122 33761	CER. CHIP 22pF ±5% CG 50V	DD95220300
C111			ELECT 100μF 10V	EJ10701010
C112			ELECT 100μF 10V	EJ10701010
C113		4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C114			ELECT 47μF 10V	EJ47601010
C115		4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C116	330/331	4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C117	330/331	4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C118		4822 122 31765	CER. CHIP 100pF ±5% CG 50V	DD95101300
C119	330		CER. CHIP 2pF ±0.25pF CK	DD90020300
C120		4822 126 14417	CER. CHIP 0.01μF ±10% 50V K	DK96103300
C201		5322 126 11578	CER. CHIP 1000pF ±10% B	DK96102300
C202		5322 126 11578	CER. CHIP 1000pF ±10% B	DK96102300
C203			ELECT 100μF 10V	EJ10701010
C204		4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C205		4822 126 11685	CER. CHIP 4700P ±10% 50V	DK96472300
C206	330/331	4822 126 11685	CER. CHIP 4700P ±10% 50V	DK96472300
C207			ELECT 100μF 10V	EJ10701010
C208		4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C209		5322 126 11578	CER. CHIP 1000pF ±10% B	DK96102300
C210		5322 126 11578	CER. CHIP 1000pF ±10% B	DK96102300
C211		5322 126 11578	CER. CHIP 1000pF ±10% B	DK96102300
C212		5322 126 11578	CER. CHIP 1000pF ±10% B	DK96102300
C213		4822 126 11568	CER. CHIP 470pF ±10%	DK96471300
C214			CER. CHIP 0.22μF ±10% B 16V	DK56224200
C215	330/331	4822 126 11568	CER. CHIP 470pF ±10%	DK96471300
C216		4822 126 14417	CER. CHIP 0.01μF ±10% 50V K	DK96103300
C217			CER. CHIP 0.47μF ±10% 16V B	DK56474200
C218	331	4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C251	340	4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C252	340	4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C253	340	4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C254	340		ELECT 100μF 10V	EJ10701010
C255	340	4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C256	340	4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C257	340	4822 126 13837	CER. CHIP 0.1μF ±10% B 10V	DK96104200
C258	340	4822 126 13396	CER. CHIP 0.047μF ±10% 16V	DK96473200
<b>P101-RESISTORS</b>				
R101		4822 051 30681	CHIP 680Ω ±5% 1/16W	NN05681610
R102		4822 051 30681	CHIP 680Ω ±5% 1/16W	NN05681610
R103		4822 051 30223	CHIP 22kΩ ±5% 1/16W	NN05223610
R104		4822 051 30223	CHIP 22kΩ ±5% 1/16W	NN05223610
R105		4822 117 12925	CHIP 47kΩ ±5% 1/16W	NN05473610
R106		4822 051 30153	CHIP 15kΩ ±5% 1/16W	NN05153610
R107		4822 051 30102	CHIP 1kΩ ±5% 1/16W	NN05102610
R108		4822 051 30152	CHIP 1.5kΩ ±5% 1/16W	NN05152610
R109		4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
R110		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
R111		4822 051 30333	CHIP 33kΩ ±5% 1/16W	NN05333610
R112		4822 051 30333	CHIP 33kΩ ±5% 1/16W	NN05333610
R113		4822 051 30562	CHIP 5.6kΩ ±5% 1/16W	NN05562610
R114		4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
R116		4822 117 12891	CHIP 220kΩ ±5% 1/16W	NN05224610
R117		4822 051 30102	CHIP 1kΩ ±5% 1/16W	NN05102610
R118		4822 051 30102	CHIP 1kΩ ±5% 1/16W	NN05102610
R121		4822 117 13632	CHIP 100kΩ ±5% 1/16W	NN05104610
R123		4822 117 13632	CHIP 100kΩ ±5% 1/16W	NN05104610

POS. NO	VERS. COLOR	PART NO. (FOR PCS)	DESCRIPTION	PART NO. (MJI)
R124		4822 051 30102	CHIP 1kΩ ±5% 1/16W	NN05102610
R125		4822 117 12902	CHIP 8.2kΩ ±5% 1/16W	NN05822610
R126	330/331	4822 051 30332	CHIP 3.3kΩ ±5% 1/16W	NN05332610
R130				
R131	330/331	4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
R133	330/331	4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
R134		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
R135		4822 117 12902	CHIP 8.2kΩ ±5% 1/16W	NN05822610
R137	330/331	4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
R201		4822 051 30683	CHIP 68kΩ ±5% 1/16W	NN05683610
R202		4822 051 30683	CHIP 68kΩ ±5% 1/16W	NN05683610
R203		4822 051 30272	CHIP 2.7kΩ ±5% 1/16W	NN05272610
R204		4822 051 30184	CHIP 180kΩ ±5% 1/16W	NN05184610
R205		4822 051 30184	CHIP 180kΩ ±5% 1/16W	NN05184610
R206		4822 051 30333	CHIP 33kΩ ±5% 1/16W	NN05333610
R207		4822 117 12891	CHIP 220kΩ ±5% 1/16W	NN05224610
R208		4822 117 12891	CHIP 220kΩ ±5% 1/16W	NN05224610
R209		4822 116 83819	CHIP 18kΩ ±5% 1/16W	NN05183610
R210	330/331	4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
R211	330/331	4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
R212	330/331	4822 051 30472	CHIP 4.7kΩ ±5% 1/16W	NN05472610
R213	330/331	4822 051 30102	CHIP 1kΩ ±5% 1/16W	NN05102610
R214		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
R215		4822 051 30153	CHIP 15kΩ ±5% 1/16W	NN05153610
R216		4822 051 30123	CHIP 12kΩ ±5% 1/16W	NN05123610
R217	331/340	4822 051 30153	CHIP 15kΩ ±5% 1/16W	NN05153610
R251	340		CHIP 82Ω ±5% 1/10W	NI05820110
R252	340		CHIP 82Ω ±5% 1/10W	NI05820110
R253	340	4822 051 30682	CHIP 6.8kΩ ±5% 1/16W	NN05682610
R254	340	4822 051 30682	CHIP 6.8kΩ ±5% 1/16W	NN05682610
R255	340	4822 051 30682	CHIP 6.8kΩ ±5% 1/16W	NN05682610
R256	340	4822 117 13632	CHIP 100kΩ ±5% 1/16W	NN05104610
R257	340	4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
R258	340	4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
R259	340		CHIP 2.2Ω ±5% 1/10W	NI05022110
R260	340		CHIP 2.2Ω ±5% 1/10W	NI05022110
R261	340		CHIP 2.2Ω ±5% 1/10W	NI05022110
R262	340	4822 051 30223	CHIP 22kΩ ±5% 1/16W	NN05223610
R263	340	4822 051 30223	CHIP 22kΩ ±5% 1/16W	NN05223610
R264	340	4822 051 30223	CHIP 22kΩ ±5% 1/16W	NN05223610
R265	340	4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
R266	340		CHIP 2.2Ω ±5% 1/10W	NI05022110
<b>P101-SEMICONDUCTORS</b>				
Q101	330/331	9965 000 01600	IC TZA1022 HF AMP/LA CONT	HC10180490
Q102		9965 000 01720	IC NJM2137M-TE1 DUAL OP	HC10206090
Q103		4822 209 30455	IC NJM2100M JRC	HC10085090
Q104		4822 130 61906	DIG.TRS. DTC114EU	BA20035210
Q105		4822 130 61906	DIG.TRS. DTC114EU	BA20035210
Q106		4822 130 60731	CHIP TRS. 2SA1036K Q R	HX110362B0
Q107		4822 130 61906	DIG.TRS. DTC114EU	BA20035210
Q108		4822 130 11357	DIG.TRS. RN2307 DTA114YU	BA12307000
Q109		9965 000 01601	THERMISTOR	HH50005780
			TN10-4C103JT 10k	
Q110	331/340	4822 130 61906	DIG.TRS. DTC114EU	BA20035210
Q112	340	9965 000 01601	THERMISTOR	HH50005780
			TN10-4C103JT 10k	
Q201		4822 209 16372	IC TDA7073AT	HC10165490
			SOP DUAL BTL DRIVER	
Q202		4822 209 16372	IC TDA7073AT	HC10165490
			SOP DUAL BTL DRIVER	
Q203	331/340	9965 000 01601	THERMISTOR	HH50005780
			TN10-4C103JT 10k	
Q251	340	4822 209 16877	IC BA6856FP	HC10213210
			3PH-MOTOR DRIVER	
Q252	340	4822 130 60731	CHIP TRS. 2SA1036K Q R	HX110362B0



POS. NO	VERS. COLOR	PART NO. (FOR PCS)	DESCRIPTION	PART NO. (MJI)	POS. NO	VERS. COLOR	PART NO. (FOR PCS)	DESCRIPTION	PART NO. (MJI)
J101 J102 J202			<b>P101-MISCELLANEOUS</b> JACK 16FMZ-ST FFC CONN. JACK 20FE-ST-VK-N 20PIN JACK 11FM-1.0ST FFC CONN.	YJ07020820 YJ07020160 YJ07020830	CD10 CD11 CD12 CD13 CD14 CD15 CD16 CD17 CD18 CD19 CD19 CD20 CD21 CD22 CD23		9965 000 00599 9965 000 00599 4822 126 13837 4822 122 32672 5322 124 41744 4822 126 13689 4822 122 33752 4822 126 13837 4822 126 13396 4822 126 11671 5322 126 14449 4822 122 33753 4822 126 13689 5322 126 11578 4822 122 31765	CER. CHIP 0.22μF ±10% B 10V CER. CHIP 0.22μF ±10% B 10V CER. CHIP 0.1μF ±10% B 10V TANTL.CHIP 1μF 16V ELECT. 4700μF 10V RA-2 CER. CHIP 18pF ±5% CER. CHIP 15pF ±5% CG 50V CER. CHIP 0.1μF ±10% B 10V CER. CHIP 0.047μF ±10% X7R CER. CHIP 33pF ±5% CG 50V CER. CHIP 39pF ±5% CG 50V CER. CHIP 150pF ±5% CG 50V CER. CHIP 18pF ±5% CG 50V CER. CHIP 1000pF ±10% B CER. CHIP 100pF ±5% CG 50V	DK96224200 DK96224200 DK96104200 EY10501610 OA47801020 DD95180300 DD95150300 DK96104200 DK96473200 DD95330300 DD95390300 DD95151300 DD95180300 DK96102300 DD95101300
▲ L801	/F, /U		<b>P801-TRANS CIRCUIT BOARD</b> MAINS TRANSF. EI-57 100V/120V	TS15747010					
▲ L801	/N	9965 000 01599	MAINS TRANSF. EI-57 230V	TS15747020					
▲ C851 ▲ L851 ▲ S851		4822 122 33276 4822 157 70419 4822 276 13364	<b>P851-POWER SW CIRCUIT BOARD</b> CER. DE7150 F 103M VA1 KC LF-4D-102 PUSH SWITCH SDDL1 POWER TV-3	DK17103840 FN01020020 SP01011990					
			<b>PB01-XLR CONN. CIRCUIT BOARD [PMD331/340]</b> <b>PB01-CAPACITORS</b> ELECT. 220μF M 6.3V RA-2 CER. 50V DC 0.1μF +80 -20% CER. 0.01μF ±10% 50V CER. 0.01μF ±10% 50V CER. 220pF ±10% 50V CER. 220pF ±10% 50V	OA22700620 DD38104010 DK16103300 DK16103300 DK16221300 DK16221300					
CT52 CT53 CT56 CT57 CT58 CT59	331/340 331/340 331/340 331/340 331/340 331/340	4822 124 41537	<b>PB01-RESISTORS</b> 56Ω ±5% 1/6W 56Ω ±5% 1/6W	GG05560160 GG05560160	CM01 CT01 CT03 CT04 CT07 CT08		5322 122 32654 4822 126 13837 4822 126 12339 4822 126 13837 4822 126 13837 4822 124 22275	CER. CHIP 0.022μF ±10% 16V CER. CHIP 0.1μF ±10% B 10V CER. CHIP 2200P ±10% 50V CER. CHIP 0.1μF ±10% B 10V CER. CHIP 0.1μF ±10% B 10V ELECT. 47μF M 10V RA-2	DK96223200 DK96104200 DK96222300 DK96104200 DK96104200 OA47601020
RT52 RT53	331/340 331/340		<b>PB01-SEMICONDUCTOR</b> IC SN75158/P TEXAS INST.	HC10071370	CU01 CU02 CU03 CU04 CU05 CU41 CU51 CU53 CU54 CU60 CU79 CU80 CU91		4822 122 33752 4822 122 33752 4822 126 13837 4822 126 13837 4822 124 41543 4822 126 13837 4822 124 90352 4822 126 13837 5322 126 11578 5322 126 11578 4822 126 13837 4822 126 13837	CER. CHIP 15pF ±5% CG 50V CER. CHIP 15pF ±5% CG 50V CER. CHIP 0.1μF ±10% B 10V CER. CHIP 0.1μF ±10% B 10V ELECT. 1μF M 50V RA-2 CER. CHIP 0.1μF ±10% B 10V ELECT. 10μF M 16V RA-2 CER. CHIP 0.1μF ±10% B 10V CER. CHIP 1000pF ±10% B CER. CHIP 1000pF ±10% B	DD95150300 DD95150300 DK96104200 DK96104200 OA10505020 DK96104200 OA10601620 DK96104200 DK96102300
JB53 JB54 JT53	331/340 331/340 331/340		<b>PB01-MISCELLANEOUS</b> JACK NC3MAH 3P CANNON JACK NC3MAH 3P CANNON JACK NC3MAH 3P CANNON	YJ01004070 YJ01004070 YJ01004070	C301 C302 C303 C304 C305	331/340	4822 124 90352 4822 126 13837 4822 126 13837 4822 126 13837 4822 126 13396	ELECT. 10μF M 16V RA-2 CER. CHIP 0.1μF ±10% B 10V CER. CHIP 0.1μF ±10% B 10V CER. CHIP 0.1μF ±10% B 10V CER. CHIP 0.047μF ±10% X7R	OA10601620 DK96104200 DK96104200 DK96104200 DK96473200
LT52 LT53 LT54	331/340 331/340 331/340	4822 242 73843 4822 148 81381	EMI FILTER DSS306-91-F-223Z PULSE TRANSF. TC-1086-26 FERRITE CORE BL02RN1-R62T2 FERRITE CORE BL02RN1-R62T2	FM12223010 TP33842010 FC90050040 FC90050040					
LT55	331/340		<b>PD01-MAIN CIRCUIT BOARD</b> <b>PD01-CAPACITORS</b> ELECT. 100μF M 16V RA-2	OA10701620	C501 C502 C503 C504 C505 C506 C507 C508 C509 C510 C511 C512 C513 C514 C515 C516 C517 C518 C522 C523 C524 C525 C526 C541		4822 124 90352 4822 124 90352 4822 122 33761 4822 122 33761 4822 122 33753 4822 122 33753 4822 122 33753 4822 122 33753 4822 124 90354 4822 124 90354 5322 126 11578 5322 126 11578 4822 126 13837 4822 126 13837 4822 124 90352 4822 126 13837 4822 126 13837 4822 124 90352 4822 124 90354 4822 124 90354 4822 126 13837 4822 126 13837 4822 126 13837	ELECT. 10μF M 16V RA-2 ELECT. 10μF M 16V RA-2 CER. CHIP 22pF ±5% CG 50V CER. CHIP 22pF ±5% CG 50V CER. CHIP 150pF ±5% 50V CER. CHIP 150pF ±5% 50V CER. CHIP 150pF ±5% 50V ELECT. 100μF M 16V RA-2 ELECT. 100μF M 16V RA-2 CER. CHIP 1000pF ±10% B CER. CHIP 1000pF ±10% B CER. CHIP 0.1μF ±10% B 10V CER. CHIP 0.1μF ±10% B 10V CER. CHIP 0.1μF ±10% B 10V ELECT. 10μF M 16V RA-2 CER. CHIP 0.1μF ±10% B 10V ELECT. 10μF M 16V RA-2 ELECT. 100μF M 16V RA-2 ELECT. 100μF M 16V RA-2 CER. CHIP 0.1μF ±10% B 10V CER. CHIP 0.1μF ±10% B 10V CER. CHIP 0.1μF ±10% B 10V	OA10601620 OA10601620 DD95220300 DD95220300 DD95151300 DD95151300 DD95151300 OA10701620 OA10701620 DK96102300 DK96102300 DK96104200 DK96104200 DK96104200 OA10601620 DK96104200 OA10601620 OA10701620 OA10701620 DK96104200 DK96104200 DK96104200
CB01 CB02 CB06 CB07 CB13 CB14 CB21	331/340 331/340 331/340 331/340 331/340 331/340 331/340	4822 124 90354 4822 124 90352 4822 124 90354	ELECT. 100μF M 16V RA-2 ELECT. 10μF M 16V RA-2 ELECT. 100μF M 16V RA-2	OA10701620 OA10601620 OA10701620					
CD01 CD01 CD02 CD03 CD04 CD05 CD06 CD07 CD08 CD09	330/331 340	4822 126 11685 4822 126 4822 126 13396 5322 126 11578 5322 126 11578 4822 126 14417 4822 126 13396 4822 126 12495 5322 126 11578	CER. CHIP 4700pF ±10% B 50V CER. CHIP 3300pF ±10% B 50V CER. CHIP 0.047μF ±10% X7R CER. CHIP 1000pF ±10% B CER. CHIP 1000pF ±10% B CER. CHIP 0.01μF ±10% 50V K CER. CHIP 0.47μF ±10% 16V B CER. CHIP 0.047μF ±10% X7R CER. CHIP 1500P ±10% 50V CER. CHIP 1000P ±10% 50V	DK96472300 DK96332300 DK96473200 DK96102300 DK96102300 DK96103300 DK56474200 DK96473200 DK96152300 DK96102300					

POS. NO	VERS. COLOR	PART NO. (FOR PCS)	DESCRIPTION	PART NO. (MJI)
C801	330	4822 124 22243	ELECT 6800μF 16V RE3	OA68801620
C801	331/340		ELECT 10000μF 16V RE3	EA10901670
C802			CER. 0.1μF +80%-20% 50V	DD38104010
C803			CER. 0.1μF +80%-20% 50V	DD38104010
C804		4822 124 90371	ELECT. 470μF M 10V RA-2	OA47701020
C805			CER. 0.1μF +80%-20% 50V	DD38104010
C806			CER. 0.1μF +80%-20% 50V	DD38104010
C807		4822 124 90371	ELECT. 470μF M 10V RA-2	OA47701020
C808		4822 124 11583	ELECT. 2200μF M 35V RA-2	OA22803520
C809		4822 124 11583	ELECT. 2200μF M 35V RA-2	OA22803520
C810			CER. 0.1μF +80%-20% 50V	DD38104010
C811			CER. 0.1μF +80%-20% 50V	DD38104010
C812			CER. 0.1μF +80%-20% 50V	DD38104010
C813			CER. 0.1μF +80%-20% 50V	DD38104010
C814		4822 124 22277	ELECT. 470μF 16V M RA-2	OA47701620
C815		4822 124 22277	ELECT. 470μF 16V M RA-2	OA47701620
C816		4822 124 41543	ELECT. 1μF M 50V RA-2	OA10505020
<b>PD01-RESISTORS</b>				
RB01	331/340	9965 000 01716	VARIABLE 10kΩ B	RK01031580
RB02	331/340	9965 000 01716	VARIABLE 10kΩ B	RK01031580
RB03	331/340	4822 051 30221	CHIP 220Ω ±5% 1/16W	NN05221610
RB04	331/340	4822 051 30221	CHIP 220Ω ±5% 1/16W	NN05221610
RB05	331/340	4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RB06	331/340	4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RB07	331/340	4822 051 30682	CHIP 6.8kΩ ±5% 1/16W	NN05682610
RB08	331/340	4822 051 30682	CHIP 6.8kΩ ±5% 1/16W	NN05682610
RB09	331/340	4822 051 30223	CHIP 22kΩ ±5% 1/16W	NN05223610
RB10	331/340	4822 051 30223	CHIP 22kΩ ±5% 1/16W	NN05223610
RB11	331/340	4822 051 30223	CHIP 22kΩ ±5% 1/16W	NN05223610
RB12	331/340	4822 051 30223	CHIP 22kΩ ±5% 1/16W	NN05223610
RB13				
RB24	331/340	4822 051 30472	CHIP 4.7kΩ ±5% 1/16W	NN05472610
RB25				
RB28				
RB29				
RB32	331/340	4822 051 30472	CHIP 4.7kΩ ±5% 1/16W	NN05472610
RB33				
RB36	331/340	4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RD01		4822 051 30222	CHIP 2.2kΩ ±5% 1/16W	NN05222610
RD02		4822 051 30153	CHIP 15kΩ ±5% 1/16W	NN05153610
RD03		4822 051 30153	CHIP 15kΩ ±5% 1/16W	NN05153610
RD04		4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
RD05		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RD06		4822 117 13632	CHIP 100kΩ ±5% 1/16W	NN05104610
RD07		4822 051 30332	CHIP 3.3kΩ ±5% 1/16W	NN05332610
RD08		4822 051 30332	CHIP 3.3kΩ ±5% 1/16W	NN05332610
RD09		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RD10		4822 051 30105	CHIP 1MΩ ±5% 1/16W	NN05105610
RD11		4822 051 30223	CHIP 22kΩ ±5% 1/16W	NN05223610
RD12		4822 117 12925	CHIP 47kΩ ±5% 1/16W	NN05473610
RD13		4822 051 30333	CHIP 33kΩ ±5% 1/16W	NN05333610
RD15		4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
RD16		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RD17		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RD18		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RD19		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RD20		4822 051 30102	CHIP 1kΩ ±5% 1/16W	NN05102610
RD22		4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
RD23	331	4822 116 83819	CHIP 18kΩ ±5% 1/16W	NN05183610
RD23	340	4822 051 30153	CHIP 15kΩ ±5% 1/16W	NN05153610
▲ RM01		4822 111 90967	FUSE 4.7Ω J 1/4W	NF05047140
RM02		4822 051 30681	CHIP 680Ω ±5% 1/16W	NN05681610
RT02		4822 051 30221	CHIP 220Ω ±5% 1/16W	NN05221610

POS. NO	VERS. COLOR	PART NO. (FOR PCS)	DESCRIPTION	PART NO. (MJI)
RT03		4822 051 30331	CHIP 330Ω ±5% 1/16W	NN05331610
RT04		4822 051 30759	CHIP 75Ω ±5% 1/16W	NN05750610
RU01		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RU02		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RU04		4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
RU05	330/331	4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
RU06		4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
RU07		4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
RU08		4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
RU09		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RU10	330/340	4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
RU11				
RU21		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RU22		4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
RU23				
RU27		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RU28		4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
RU30		4822 051 30105	CHIP 1MΩ ±5% 1/16W	NN05105610
RU31		4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
RU32	330	4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RU41		4822 051 30472	CHIP 4.7kΩ ±5% 1/16W	NN05472610
RU42		4822 051 30472	CHIP 4.7kΩ ±5% 1/16W	NN05472610
RU51		4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
RU52		4822 117 12925	CHIP 47kΩ ±5% 1/16W	NN05473610
RU53		4822 116 83819	CHIP 18kΩ ±5% 1/16W	NN05183610
RU54		4822 051 30479	CHIP 47Ω ±5% 1/16W	NN05470610
RU55		4822 051 30102	CHIP 1kΩ ±5% 1/16W	NN05102610
RU58		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RU60	331/340	4822 051 30102	CHIP 1kΩ ±5% 1/16W	NN05102610
RU62				
RU74	331/340	4822 051 30102	CHIP 1kΩ ±5% 1/16W	NN05102610
RU80				
RU90	331/340	4822 117 12925	CHIP 47kΩ ±5% 1/16W	NN05473610
RU91		4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
RU92		4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
RU93	331/340	4822 117 12925	CHIP 47kΩ ±5% 1/16W	NN05473610
RU94	331/340	4822 117 12925	CHIP 47kΩ ±5% 1/16W	NN05473610
RU95	331/340	4822 117 12925	CHIP 47kΩ ±5% 1/16W	NN05473610
R301	331/340	4822 051 30474	CHIP 470kΩ ±5% 1/16W	NN05474610
R501		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
R502		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
R503		4822 051 30472	CHIP 4.7kΩ ±5% 1/16W	NN05472610
R504		4822 051 30472	CHIP 4.7kΩ ±5% 1/16W	NN05472610
R505		4822 116 83819	CHIP 18kΩ ±5% 1/16W	NN05183610
R506		4822 116 83819	CHIP 18kΩ ±5% 1/16W	NN05183610
R507		4822 051 30333	CHIP 33kΩ ±5% 1/16W	NN05333610
R508		4822 051 30333	CHIP 33kΩ ±5% 1/16W	NN05333610
R509		4822 051 30123	CHIP 12kΩ ±5% 1/16W	NN05123610
R510		4822 051 30123	CHIP 12kΩ ±5% 1/16W	NN05123610
R511		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
R512		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
R513		4822 051 30223	CHIP 22kΩ ±5% 1/16W	NN05223610
R514		4822 051 30223	CHIP 22kΩ ±5% 1/16W	NN05223610
R515		4822 051 30151	CHIP 150Ω ±5% 1/16W	NN05151610
R516		4822 051 30151	CHIP 150Ω ±5% 1/16W	NN05151610
R517		4822 117 12925	CHIP 47kΩ ±5% 1/16W	NN05473610
R518		4822 117 12925	CHIP 47kΩ ±5% 1/16W	NN05473610
R519		4822 051 30471	CHIP 470Ω ±5% 1/16W	NN05471610
R520		4822 051 30471	CHIP 470Ω ±5% 1/16W	NN05471610
R531	330	4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
R532	330	4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
R533	330	4822 116 82487	CHIP 0Ω ±5% 1/16W	NN05000610
R541	331/340	4822 117 13632	CHIP 100kΩ ±5% 1/16W	NN05104610
R542	331/340	4822 051 30222	CHIP 2.2kΩ ±5% 1/16W	NN05222610

POS. NO	VERS. COLOR	PART NO. (FOR PCS)	DESCRIPTION	PART NO. (MJI)	POS. NO	VERS. COLOR	PART NO. (FOR PCS)	DESCRIPTION	PART NO. (MJI)
R543	331/340	4822 051 30222	CHIP 2.2kΩ ±5% 1/16W	NN05222610	JD01			<b>PD01-MISCELLANEOUS</b>	
R544	331/340	4822 051 30102	CHIP 1kΩ ±5% 1/16W	NN05102610	JT01		4822 267 31729	JACK 20FE-BT-VK-N 20PIN	YJ07020530
R801					JT02	331/340	4822 267 31369	TERMINAL 14X14 RA 1L1P BLK	YT02010780
⌋								OPT. CONN.GP1F32T	YJ15000090
R805		4822 051 30472	CHIP 4.7kΩ ±5% 1/16W	NN05472610				OPTICAL OUTPUT	
					JU01			JACK 30PIN 30FMN-BMTTR-TB	YJ07016500
					JU51			TERMINAL RCA JACK ORG	YT02021090
DB01	331/340	4822 130 83715	CHIP DIODE 1SS301 DAN202U	HZ21005000	JU53	331/340	4822 265 11401	PLUG D-SUB 25P FEMALE	YP11000180
DB02	331/340	4822 130 83715	CHIP DIODE 1SS301 DAN202U	HZ21005000	J501		4822 267 31727	TERMINAL 14X14 RCA 2L2P	YT02021210
DM02		9965 000 01598	CHIP DIODE	HZ30821000					
			UDZS8.2B MA8082-M		LB01	331/340	9965 000 01343	RELAY RELAY MR62-12SR	LY20120510
DU01		9965 000 01491	CHIP DIODE DA227	HZ20032210	LB02	331/340	9965 000 01343	RELAY RELAY MR62-12SR	LY20120510
			ARRAY 2PIECES-2125		LD01			CHIP INDUCTANCE	LU04472010
DU02		9965 000 01491	CHIP DIODE DA227	HZ20032210				4.7μH ±10% 1608 TYPE	
			ARRAY 2PIECES-2125		LD02			CHIP INDUCTANCE	LU04472010
DU03		4822 130 83715	CHIP DIODE 1SS301 DAN202U	HZ21005000				4.7μH ±10% 1608 TYPE	
DU51		4822 130 83715	CHIP DIODE 1SS301 DAN202U	HZ21005000	LD03			CHIP INDUCTANCE	LU04471010
DU52		4822 130 83715	CHIP DIODE 1SS301 DAN202U	HZ21005000	LD04			0.47μH ±10% MLF1608	
D501		4822 130 83715	CHIP DIODE 1SS301 DAN202U	HZ21005000				CHIP INDUCTANCE	LU04471010
D502		4822 130 81324	CHIP DIODE 1SS302	HZ20018050				0.47μH ±10% MLF1608	
▲ D801		4822 130 83067	DIODE D3SB 20	HE20020290	LT01		4822 142 60388	PULSE TRANSF. FOR CD	TP41042010
			V=200V IO=3.0A		LT02			FERRIT BEADS	FC90020120
▲ D802		4822 130 10413	DIODE BRIDGE D2SBA20	HE20027290				BK1608HM102-T	
D803		4822 130 83715	CHIP DIODE 1SS301 DAN202U	HZ21005000	LT03	331/340		FERRIT BEADS	FC90020120
								BK1608HM102-T	
QB01					L501		9965 000 01343	RELAY MR62-12SR	LY20120510
⌋									
QB04	331/340	4822 209 83357	IC NJM4560M JRC	HC10029090	SU51		4822 277 21789	SLIDE SWITCH SSSUI-6MM	SS02020970
QD01		9965 000 01437	IC CXD2585Q CD DECODER	HC10069250	XD01		4822 242 10883	CRYSTAL CM309S	JX16002360
QD02	331/340	9965 000 01601	THERMISTOR	HH50005780				16.9344MHz CITIZEN	
			TN10-4C103JT 10k		XU01		9965 000 01597	CRYSTAL CM309S 20MHz	JX20001360
QM01		4822 209 30193	IC LB1641 MOTOR DRIVER	HC10279030					
QU01		9965 000 01492	MICROPROCESSOR	HU371KH00F				<b>PV01-HEAD PHONE</b>	
			HD643306ZF MPU					<b>CIRCUIT BOARD</b>	
QU03		9965 000 01595	IC AT25640	HC10074990	CV01			<b>PV01-CAPACITORS</b>	
			64K EEPROM		CV02			ELECT 100μF 16V RC-2	EJ10701610
QU04		9965 000 01596	IC 74HC4094BT FLAT	HC809449R0	CV03			ELECT 100μF 16V RC-2	EJ10701610
QU41		4822 130 60731	CHIP TRS. 2SA1036K Q R	HX110362B0	CV04			ELECT 47μF 16V	EJ47601610
QU42		4822 130 61906	DIG.TRS. DTC114EU	BA20035210				ELECT 47μF 16V	EJ47601610
QU51		4822 130 60669	CHIP TRS. 2SC4081 Q R	HX300012A0					
			2SC4116 Y GR					<b>PV01-RESISTORS</b>	
QU52		4822 130 61906	DIG.TRS. DTC114EU	BA20035210	RV01		4822 051 30153	CHIP 15kΩ ±5% 1/16W	NN05153610
QU53		4822 130 11357	DIG.TRS. RN2307 DTA114YU	BA12307000	RV02		4822 051 30153	CHIP 15kΩ ±5% 1/16W	NN05153610
QU55		4822 130 11357	DIG.TRS. RN2307 DTA114YU	BA12307000	RV03		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
QU56		9965 000 01596	IC 74HC4094BT FLAT	HC809449R0	RV04		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
QU57		4822 209 17428	IC 74HC165F	HC716500R0	RV05		9965 000 01489	CHIP 120Ω ±5% 1/2W	RI05121120
QU58		4822 209 17428	IC 74HC165F	HC716500R0	RV06		9965 000 01489	CHIP 120Ω ±5% 1/2W	RI05121120
QU59					RV07		4822 051 30472	CHIP 4.7kΩ ±5% 1/16W	NN05472610
⌋					RV08		4822 051 30472	CHIP 4.7kΩ ±5% 1/16W	NN05472610
QU64		4822 130 61906	DIG.TRS. DTC114EU	BA20035210	RV09		9965 000 01490	VARIABLE 50kΩ A L=15MM	RM05033070
QU91		4822 209 30426	IC CMOS 74HC00 FLAT	HC700000Z0					
					QV01		4822 209 31378	<b>PV01-SEMICONDUCTOR</b>	
Q301	331/340	9965 000 01717	IC RL5C357 SHOCK PROOF	HC10042770				IC NJM4556AM JRC	HC10045090
Q302	331/340	9965 000 01718	IC HY5117400BJ-60 DRAM	HC10089990					
Q501		4822 209 15226	IC PCM1710U 16/20BIT DAC	HC10004610				<b>PV01-MISCELLANEOU</b>	
Q502		4822 209 83357	IC NJM4560 FLAT PACK JRC	HC10029090	JV02		4822 267 31126	JACK ST HEADPHONE BL/GL	YJ01003020
Q541	331/340	4822 130 11357	DIG.TRS. RN2307 DTA114YU	BA12307000					
Q542	331/340	4822 130 43818	TRS. 2SC2878 A OR B	HT328782A0				<b>PY01-DISPLAY</b>	
Q543	331/340	4822 130 43818	TRS. 2SC2878 A OR B	HT328782A0				<b>CIRCUIT BOARD</b>	
▲ Q801		4822 209 83824	IC NJM7805FA +5V 1A JRC	HC38905090				<b>PY01-CAPACITORS</b>	
▲ Q802		4822 209 73674	IC NJM7806FA +6V 1A JRC	HC38906090	CY01		9965 000 01438	TANTL.CHIP 2.2μF 50V	EY22505020
▲ Q803		4822 209 82829	IC NJM78M15FA +15V 0.5A	HC38515090	CY02		9965 000 01438	TANTL.CHIP 2.2μF 50V	EY22505020
▲ Q804		4822 209 83828	IC NJM79M15FA -15V 0.5A	HC39515090	CY03		9965 000 01438	TANTL.CHIP 2.2μF 50V	EY22505020
Q805		4822 130 61906	DIG.TRS. DTC114EU	BA20035210	CY04		4822 124 23002	TANTL.CHIP 10μF 16V	EY10601620
Q806		4822 130 61906	DIG.TRS. DTC114EU	BA20035210	CY05		4822 126 14417	CER. CHIP 0.01μF ±10% 50V K	DK96103300
					CY06		4822 124 11226	TANTL.CHIP 22μF 6.3V	EY22600620
					CY07		4822 126 14417	CER. CHIP 0.01μF ±10% 50V K	DK96103300
					CY08		4822 126 14417	CER. CHIP 0.01μF ±10% 50V K	DK96103300
					CY09		4822 126 14417	CER. CHIP 0.01μF ±10% 50V K	DK96103300

POS. NO	VERS. COLOR	PART NO. (FOR PCS)	DESCRIPTION	PART NO. (MJI)
CY10 } CY17		5322 126 11578	CER. CHIP 1000pF ±10% B	DK96102300
			<b>PY01-RESISTORS</b>	
RY01		9965 000 01444	VARIABLE 100kΩ B W/CLIC	RB01040080
RY02		4822 051 30332	CHIP 3.3kΩ ±5% 1/16W	NN05332610
RY03		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RY04		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RY05		4822 051 30273	CHIP 27kΩ ±5% 1/16W	NN05273610
RY06		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RY07		4822 051 30103	CHIP 10kΩ ±5% 1/16W	NN05103610
RY08		4822 117 12864	CHIP 82kΩ ±5% 1/16W	NN05823610
RY09		4822 051 30101	CHIP 100Ω ±5% 1/16W	NN05101610
RY11		4822 051 30101	CHIP 100Ω ±5% 1/16W	NN05101610
RY12		4822 051 30101	CHIP 100Ω ±5% 1/16W	NN05101610
RY13		4822 051 30121	CHIP 120Ω ±5% 1/16W	NN05121610
RY14		4822 051 30121	CHIP 120Ω ±5% 1/16W	NN05121610
RY15		4822 051 30121	CHIP 120Ω ±5% 1/16W	NN05121610
RY16		4822 051 30121	CHIP 120Ω ±5% 1/16W	NN05121610
RY17		4822 051 30101	CHIP 100Ω ±5% 1/16W	NN05101610
RY18		4822 117 12891	CHIP 220kΩ ±5% 1/16W	NN05224610
RY19		4822 051 30121	CHIP 120Ω ±5% 1/16W	NN05121610
RY20		4822 051 30221	CHIP 220Ω ±5% 1/16W	NN05221610
			<b>PY01-SEMICONDUCTORS</b>	
DY01 }		9965 000 01439	L.E.D. FY1101F-TX	HI10010300
DY06			YELLOW CHIP	
DY07		9965 000 01440	L.E.D. SML-310DT	HI10103210
			ORANGE CHIP	
DY08		9965 000 01440	L.E.D. SML-310DT	HI10103210
			ORANGE CHIP	
DY09 }		9965 000 01441	L.E.D. SML-310MT	HI10104210
DY12			GREEN CHIP	
DY13 }		9965 000 01440	L.E.D. SML-310DT	HI10103210
DY18			ORANGE CHIP	
QY01		9965 000 01442	IC HD66712SA02FS LCD DRIV.	HC10132010
QY02		4822 130 60669	CHIP TRS. 2SC4081 Q R	HX300012A0
			2SC4116 Y GR	
QY05		9965 000 01443	DISPLAY UNIT LCD	HQ22801800
QY06		4822 130 61906	DIG.TRS. DTC114EU	BA20035210
QY07		4822 130 61906	DIG.TRS. DTC114EU	BA20035210
QY08		4822 130 61906	DIG.TRS. DTC114EU	BA20035210
QY09		4822 130 61906	DIG.TRS. DTC114EU	BA20035210
			<b>PY01MISCELLANEOUS</b>	
JY01			JACK 30PIN 30FMN-BMTTR-TB	YJ07016500
JY03			JUMPER LEAD ZEBRA CONN.	YU01009700
SY14 }		9965 000 01445	TACT SWITCH SKHMPW	SP01013320
SY28				
			<b>PY41-IR SENSOR</b>	
			<b>CIRCUIT BOARD</b>	
QY41		4822 130 10161	PHOTO UNIT SPS-446-4	HW10005030
			IR SENSOR SANYO	
			<b>PY51-PITCH DIAL CIRCUIT</b>	
			<b>BOARD FOR PMD331/340</b>	
SY51	331/340	9965 000 01719	ROTARY SWITCH	SR01240020
			EC16B2410207 L=20 HOL	